

2012 - Mazda6 - Transmission/ Transaxle

DTC P0734:00 [FS5A-EL]

DTC P0734:00	Gear 4 incorrect ratio
DETECTION CONDITION	• The TCM detects that revolution ratio of the input revolution to output revolution is 1.277 or more or 0.57 or less for 1 s when the following conditions are met. ▪ 4GR ▪ Vehicle speed: 30 km/h {19 mph} or more • The TCM detects that revolution ratio of the input revolution to output revolution is between 0.91—1.09 for 5 s when the following conditions are met. ▪ 4GR ▪ Vehicle speed: 46 km/h {29 mph} or more ▪ TCC operation: Off Diagnostic support note • The MIL does not illuminate. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is not available. • The DTC is stored in the TCM memory.
POSSIBLE CAUSE	• Deteriorated ATF • ATF level low • Solenoid valve malfunction ▪ Pressure control solenoid A ▪ Shift solenoid A ▪ Shift solenoid B ▪ Shift solenoid C

	Line pressure malfunction • Stall speed malfunction • Forward clutch slipping • 2-4 brake band slipping • 3-4 clutch slipping • Primary control valve body malfunction • TCM malfunction
--	--

Diagnostic procedure

STEP	INSPECTION	ACTION	
1	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	INSPECT ATF CONDITION • Inspect the ATF condition. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL].) • Is it normal?	Yes	Go to the next step.
		No	Replace the ATF, then go to Step 9. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
3	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL].) • Is it normal?	Yes	Go to the next step.
		No	Add ATF to the specified level, then go to Step 9. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
4	INSPECT SOLENOID VALVE • Inspect the following solenoid valves: (See SOLENOID VALVE INSPECTION [FS5A-EL].) ▪ Pressure control solenoid A ▪ Shift solenoid A ▪ Shift solenoid B	Yes	Replace the solenoid valve, then go to Step 9. (See SOLENOID VALVE REMOVAL/ INSTALLATION [FS5A-EL] .)
		No	Go to the next step.

	▪ Shift solenoid C • Is there any malfunction?		
5	INSPECT LINE PRESSURE • Perform the "Line Pressures Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to test result, then go to Step 9.
		No	Go to the next step.
6	INSPECT STALL SPEED • Perform the "Stall Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to test result, then go to Step 9.
		No	Go to the next step.
7	INSPECT TURBINE SPEED WHILE DRIVING VEHICLE • Connect the M-MDS. • Start the engine. • Measure the PID "TSS" while driving vehicle under the following conditions: ▪ Selector lever position: D position ▪ Gear position: 4GR ▪ Vehicle speed: 80 km/h {50 mph} • Is the PID "TSS" approx.2,350 RPM?	Yes	Go to Step 9.
		No	Go to the next step.
8	INSPECT PRIMARY CONTROL VALVE BODY • Remove the primary control valve body. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [FS5A-EL] .) • Disassemble the primary control valve body. • Inspect the following parts: ▪ Shift valve ▪ Return spring ▪ Hydraulic passage • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to inspection result, then go to next step.
		No	Replace the transaxle, then go to the next step. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FS5A-EL] .)
9	VERIFY TROUBLESHOOTING OF DTC P0734:00 COMPLETED • Make sure to reconnect all the disconnected	Yes	Replace the TCM, then go to the next step.

	connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Drive the vehicle under the following conditions for 1 s or more. ▪ 4GR ▪ Vehicle speed: 30 km/h {19 mph} or more ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 4GR ▪ Vehicle speed: 46 km/h {29 mph} or more ▪ TCC operation: Off • Is the same DTC present?	(See TCM REMOVAL/ INSTALLATION [FS5A-EL] .)
		No Go to the next step.
10	VERIFY NO DTCs ARE PRESENT • Perform the “Reading DTCs Procedure”. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FS5A-EL] .) • Are any DTCs present?	YesGo to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FS5A-EL] .) No DTC troubleshooting completed.

2012 - Mazda6 - Transmission/ Transaxle

DTC P0734:00 [FS5A-EL]

DTC P0734:00	Gear 4 incorrect ratio
DETECTION CONDITION	• The TCM detects that revolution ratio of the input revolution to output revolution is 1.277 or more or 0.57 or less for 1 s when the following conditions are met. ▪ 4GR ▪ Vehicle speed: 30 km/h {19 mph} or more • The TCM detects that revolution ratio of the input revolution to output revolution is between 0.91—1.09 for 5 s when the following conditions are met. ▪ 4GR ▪ Vehicle speed: 46 km/h {29 mph} or more ▪ TCC operation: Off Diagnostic support note • The MIL does not illuminate. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is not available. • The DTC is stored in the TCM memory.
POSSIBLE CAUSE	• Deteriorated ATF • ATF level low • Solenoid valve malfunction ▪ Pressure control solenoid A ▪ Shift solenoid A ▪ Shift solenoid B ▪ Shift solenoid C

	Line pressure malfunction • Stall speed malfunction • Forward clutch slipping • 2-4 brake band slipping • 3-4 clutch slipping • Primary control valve body malfunction • TCM malfunction
--	--

Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	INSPECT ATF CONDITION • Inspect the ATF condition. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL].) • Is it normal?	Yes	Go to the next step.
		No	Replace the ATF, then go to Step 9. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
3	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL].) • Is it normal?	Yes	Go to the next step.
		No	Add ATF to the specified level, then go to Step 9. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
4	INSPECT SOLENOID VALVE • Inspect the following solenoid valves: (See SOLENOID VALVE INSPECTION [FS5A-EL].) ▪ Pressure control solenoid A ▪ Shift solenoid A ▪ Shift solenoid B	Yes	Replace the solenoid valve, then go to Step 9. (See SOLENOID VALVE REMOVAL/ INSTALLATION [FS5A-EL] .)
		No	Go to the next step.

	▪ Shift solenoid C • Is there any malfunction?		
5	INSPECT LINE PRESSURE • Perform the "Line Pressures Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to test result, then go to Step 9.
		No	Go to the next step.
6	INSPECT STALL SPEED • Perform the "Stall Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to test result, then go to Step 9.
		No	Go to the next step.
7	INSPECT TURBINE SPEED WHILE DRIVING VEHICLE • Connect the M-MDS. • Start the engine. • Measure the PID "TSS" while driving vehicle under the following conditions: ▪ Selector lever position: D position ▪ Gear position: 4GR ▪ Vehicle speed: 80 km/h {50 mph} • Is the PID "TSS" approx.2,350 RPM?	Yes	Go to Step 9.
		No	Go to the next step.
8	INSPECT PRIMARY CONTROL VALVE BODY • Remove the primary control valve body. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [FS5A-EL] .) • Disassemble the primary control valve body. • Inspect the following parts: ▪ Shift valve ▪ Return spring ▪ Hydraulic passage • Is there any malfunction?	Yes	Repair or replace malfunctioning part according to inspection result, then go to next step.
		No	Replace the transaxle, then go to the next step. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FS5A-EL] .)
9	VERIFY TROUBLESHOOTING OF DTC P0734:00 COMPLETED • Make sure to reconnect all the disconnected	Yes	Replace the TCM, then go to the next step.

	connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Drive the vehicle under the following conditions for 1 s or more. ▪ 4GR ▪ Vehicle speed: 30 km/h {19 mph} or more ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 4GR ▪ Vehicle speed: 46 km/h {29 mph} or more ▪ TCC operation: Off • Is the same DTC present?	(See TCM REMOVAL/ INSTALLATION [FS5A-EL] .)
		No Go to the next step.
10	VERIFY NO DTCs ARE PRESENT • Perform the “Reading DTCs Procedure”. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FS5A-EL] .) • Are any DTCs present?	YesGo to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FS5A-EL] .) No DTC troubleshooting completed.