

2012 - Mazda6 - Transmission/ Transaxle

DTC P0735:00 [FS5A-EL]

DTC P0735:00	Gear 5 incorrect ratio
DETECTION CONDITION	• The TCM detects that revolution ratio of the intermediate revolution to output revolution is 1.11 or less for 5 s when the following conditions are met. ▪ 3GR or 4GR ▪ Accelerator pedal position: 4.67% or more • The TCM detects that revolution ratio of the intermediate revolution to output revolution is 1.11 or more for 5 s when the following conditions are met. ▪ 5GR ▪ Accelerator pedal position: 4.67% or more Diagnostic support note • The MIL does not illuminate. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is not available. • The DTC is stored in the TCM memory.
POSSIBLE CAUSE	• Deteriorated ATF • ATF level low • Solenoid valve malfunction ▪ Pressure control solenoid B ▪ Shift solenoid F • Line pressure malfunction • Stall speed malfunction • Direct clutch slipping • Reduction brake slipping

- Secondary control valve body malfunction
- TCM malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
2	INSPECT ATF CONDITION • Inspect the ATF condition. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL] .) • Is it normal?	Yes Go to the next step.
		No Replace the ATF, then go to Step 10. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
3	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL] .) • Is it normal?	Yes Go to the next step.
		No Add ATF to the specified level, then go to Step 10. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
4	INSPECT SOLENOID VALVE • Inspect the following solenoid valves: (See SOLENOID VALVE INSPECTION [FS5A-EL] .) ▪ Pressure control solenoid B ▪ Shift solenoid F • Is there any malfunction?	Yes Replace the solenoid valve, then go to Step 10. (See SOLENOID VALVE REMOVAL/ INSTALLATION [FS5A-EL] .)
		No Go to the next step.
5	INSPECT LINE PRESSURE • Perform the "Line Pressures Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes Repair or replace malfunctioning part according to test result, then go to Step 10.
		No Go to the next step.
6	INSPECT STALL SPEED	Yes Repair or replace malfunctioning part

	- Perform the "Stall Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) - Is there any malfunction?	according to test result, then go to Step 10. No Go to the next step.
7	INSPECT INTERMEDIATE SPEED WHILE DRIVING VEHICLE - Connect the M-MDS. - Start the engine. - Measure the PID "ISS" while driving vehicle under the following conditions: - Selector lever position: D position - Gear position: 4GR - Vehicle speed: 80 km/h {50 mph} - Is the PID "ISS" approx.3,500 RPM?	Yes Go to Step 10. No Go to the next step.
8	INSPECT INTERMEDIATE SPEED WHILE DRIVING VEHICLE - Connect the M-MDS. - Start the engine. - Measure the PID "ISS" while driving vehicle under the following conditions: - Selector lever position: D position - Gear position: 5GR - Vehicle speed: 90 km/h {56 mph} - Is the PID "ISS" approx.3,000 RPM?	Yes Go to Step 10. No Go to the next step.
9	INSPECT SECONDARY CONTROL VALVE BODY - Remove the secondary control valve body. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [FS5A-EL] .) - Disassemble the secondary control valve body. - Inspect the following parts: - Shift valve - Return spring - Hydraulic passage	Yes Repair or replace malfunctioning part according to inspection result, then go to next step. No Replace the transaxle, then go to the next step. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FS5A-EL] .)

	• Is there any malfunction?		
10	VERIFY TROUBLESHOOTING OF DTC P0735:00 COMPLETED • Make sure to reconnect all the disconnected connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 3GR or 4GR ▪ Accelerator pedal position: 4.67% or more ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 5GR ▪ Accelerator pedal position: 4.67% or more • Is the same DTC present?	Yes Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [FS5A-EL] .)	No Go to the next step.
11	VERIFY NO DTCs ARE PRESENT • Perform the "Reading DTCs Procedure". (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FS5A-EL] .) • Are any DTCs present?	Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FS5A-EL] .)	No DTC troubleshooting completed.

2012 - Mazda6 - Transmission/ Transaxle

DTC P0735:00 [FS5A-EL]

DTC P0735:00	Gear 5 incorrect ratio
DETECTION CONDITION	• The TCM detects that revolution ratio of the intermediate revolution to output revolution is 1.11 or less for 5 s when the following conditions are met. ▪ 3GR or 4GR ▪ Accelerator pedal position: 4.67% or more • The TCM detects that revolution ratio of the intermediate revolution to output revolution is 1.11 or more for 5 s when the following conditions are met. ▪ 5GR ▪ Accelerator pedal position: 4.67% or more Diagnostic support note • The MIL does not illuminate. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is not available. • The DTC is stored in the TCM memory.
POSSIBLE CAUSE	• Deteriorated ATF • ATF level low • Solenoid valve malfunction ▪ Pressure control solenoid B ▪ Shift solenoid F • Line pressure malfunction • Stall speed malfunction • Direct clutch slipping • Reduction brake slipping

- Secondary control valve body malfunction
- TCM malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
2	INSPECT ATF CONDITION • Inspect the ATF condition. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL] .) • Is it normal?	Yes Go to the next step.
		No Replace the ATF, then go to Step 10. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
3	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FS5A-EL] .) • Is it normal?	Yes Go to the next step.
		No Add ATF to the specified level, then go to Step 10. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FS5A-EL] .)
4	INSPECT SOLENOID VALVE • Inspect the following solenoid valves: (See SOLENOID VALVE INSPECTION [FS5A-EL] .) ▪ Pressure control solenoid B ▪ Shift solenoid F • Is there any malfunction?	Yes Replace the solenoid valve, then go to Step 10. (See SOLENOID VALVE REMOVAL/ INSTALLATION [FS5A-EL] .)
		No Go to the next step.
5	INSPECT LINE PRESSURE • Perform the "Line Pressures Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) • Is there any malfunction?	Yes Repair or replace malfunctioning part according to test result, then go to Step 10.
		No Go to the next step.
6	INSPECT STALL SPEED	Yes Repair or replace malfunctioning part

	- Perform the "Stall Test". (See MECHANICAL SYSTEM TEST [FS5A-EL] .) - Is there any malfunction?	according to test result, then go to Step 10. No Go to the next step.
7	INSPECT INTERMEDIATE SPEED WHILE DRIVING VEHICLE - Connect the M-MDS. - Start the engine. - Measure the PID "ISS" while driving vehicle under the following conditions: - Selector lever position: D position - Gear position: 4GR - Vehicle speed: 80 km/h {50 mph} - Is the PID "ISS" approx.3,500 RPM?	Yes Go to Step 10. No Go to the next step.
8	INSPECT INTERMEDIATE SPEED WHILE DRIVING VEHICLE - Connect the M-MDS. - Start the engine. - Measure the PID "ISS" while driving vehicle under the following conditions: - Selector lever position: D position - Gear position: 5GR - Vehicle speed: 90 km/h {56 mph} - Is the PID "ISS" approx.3,000 RPM?	Yes Go to Step 10. No Go to the next step.
9	INSPECT SECONDARY CONTROL VALVE BODY - Remove the secondary control valve body. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [FS5A-EL] .) - Disassemble the secondary control valve body. - Inspect the following parts: - Shift valve - Return spring - Hydraulic passage	Yes Repair or replace malfunctioning part according to inspection result, then go to next step. No Replace the transaxle, then go to the next step. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [FS5A-EL] .)

	• Is there any malfunction?		
10	VERIFY TROUBLESHOOTING OF DTC P0735:00 COMPLETED • Make sure to reconnect all the disconnected connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 3GR or 4GR ▪ Accelerator pedal position: 4.67% or more ◦ Drive the vehicle under the following conditions for 5 s or more. ▪ 5GR ▪ Accelerator pedal position: 4.67% or more • Is the same DTC present?	Yes Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [FS5A-EL] .)	No Go to the next step.
11	VERIFY NO DTCs ARE PRESENT • Perform the "Reading DTCs Procedure". (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FS5A-EL] .) • Are any DTCs present?	Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FS5A-EL] .)	No DTC troubleshooting completed.