

2012 - Mazda6 - Transmission/ Transaxle

KEY INTERLOCK SYSTEM INSPECTION


Key Interlock System Inspection

1. Switch the ignition to ON.
2. Perform the following procedures to inspect the key interlock system.
 - If there is any malfunction, inspect the key interlock solenoid and NOT P position switch. (See [Key Interlock Solenoid Inspection.](#)) (See [NOT P Position Switch Inspection.](#))
 - a. Verify that the ignition cannot be switched to off when the selector lever is not in the P position.
 - b. Verify that the ignition can be switched to off when the selector lever is in the P position.

Key Interlock Solenoid Inspection


CAUTION:

- Water or foreign objects entering the connector can cause a poor connection or corrosion. Be sure not to drop water or foreign objects on the connector when disconnecting it.
1. Disconnect the key interlock solenoid connector.
 - a. Disconnect the negative battery cable.
 - b. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION.](#))
 - c. Disconnect the key interlock solenoid connector.



2. Measure the resistance between key interlock solenoid terminals A and B.

KEY INTERLOCK SOLENOID



- If there is any malfunction, replace the steering lock. (See [STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION \[WITH ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .) (See [STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION \[WITHOUT ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .)

Key interlock solenoid specification

- 22.95—28.05 ohms


NOT P Position Switch Inspection

CAUTION:

- Water or foreign objects entering the connector can cause a poor connection or corrosion. Be sure not to drop water or foreign objects on the connector when disconnecting it.



1. Disconnect the selector lever component connector.

- a. Disconnect the negative battery cable.
- b. Remove the rear console. (See [REAR CONSOLE REMOVAL/ INSTALLATION](#) .)
- c. Disconnect the selector lever component connector.



2. Measure the continuity between selector lever component terminals G and K.

SELECTOR LEVER COMPONENT



- If there is any malfunction, replace the selector lever component. (See [AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/ INSTALLATION.](#))

NOT P position switch specification

Test condition	Continuity
P position	No continuity
Except P position	Continuity

2012 - Mazda6 - Transmission/ Transaxle

KEY INTERLOCK SYSTEM INSPECTION


Key Interlock System Inspection

1. Switch the ignition to ON.
2. Perform the following procedures to inspect the key interlock system.
 - If there is any malfunction, inspect the key interlock solenoid and NOT P position switch. (See [Key Interlock Solenoid Inspection.](#)) (See [NOT P Position Switch Inspection.](#))
 - a. Verify that the ignition cannot be switched to off when the selector lever is not in the P position.
 - b. Verify that the ignition can be switched to off when the selector lever is in the P position.

Key Interlock Solenoid Inspection


CAUTION:

- Water or foreign objects entering the connector can cause a poor connection or corrosion. Be sure not to drop water or foreign objects on the connector when disconnecting it.
1. Disconnect the key interlock solenoid connector.
 - a. Disconnect the negative battery cable.
 - b. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION.](#))
 - c. Disconnect the key interlock solenoid connector.



2. Measure the resistance between key interlock solenoid terminals A and B.

KEY INTERLOCK SOLENOID



- If there is any malfunction, replace the steering lock. (See [STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION \[WITH ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .) (See [STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION \[WITHOUT ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .)


Key interlock solenoid specification

- 22.95—28.05 ohms

NOT P Position Switch Inspection



CAUTION:

- Water or foreign objects entering the connector can cause a poor connection or corrosion. Be sure not to drop water or foreign objects on the connector when disconnecting it.
1. Disconnect the selector lever component connector.
 - a. Disconnect the negative battery cable.
 - b. Remove the rear console. (See [REAR CONSOLE REMOVAL/ INSTALLATION](#) .)
 - c. Disconnect the selector lever component connector.



2. Measure the continuity between selector lever component terminals G and K.

SELECTOR LEVER COMPONENT



- If there is any malfunction, replace the selector lever component. (See [AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/ INSTALLATION.](#))

NOT P position switch specification

Test condition	Continuity
P position	No continuity
Except P position	Continuity