


2012 - Mazda6 - Engine


DTC P0113:00 [MZI 3.7 V6]

DTC P0113:00	IAT sensor circuit high input
DETECTION CONDITION	Indicates the sensor signal is more than the self-test maximum. The IAT sensor maximum is 4.6 V or –50 °C { –58 °F } .
POSSI BLE CAUSE	- Connector or terminal malfunction - IAT sensor malfunction - Short to power supply between MAF/IAT sensor terminal F and PCM terminal 1P - Open circuit between MAF/IAT sensor terminal F and PCM terminal 1P - Open circuit between MAF/IAT sensor terminal E and PCM terminal 1AT

IAT SENSOR (MAF/IAT SENSOR)







PCM



PCM WIRING HARNESS-SIDE CONNECTOR

MAF/IAT SENSOR WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED Has FREEZE FRAME DATA been recorded?	Yes Go to the next step.
		No Record FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related Service Bulletins available?	Yes Perform repair or diagnosis according to the available Service Bulletins. If the vehicle is not repaired, go to the next step.
		No Go to the next step.

3	INSPECT IAT SENSOR CONNECTOR FOR POOR CONNECTION - Switch the ignition to off. - Disconnect MAF/IAT sensor connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Are there any malfunction?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
4	CLASSIFY IAT SENSOR MALFUNCTION OR HARNESS MALFUNCTION - Disconnect the MAF/IAT sensor connector. - Switch the ignition to ON (Engine off). - Measure voltage between MAF/IAT sensor terminal F (wiring harness-side) and body ground. - Is voltage 4.5—5.5 V?	Yes	Inspect the IAT sensor. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [MZI 3.7 V6] .) Replace if necessary, then go to Step 9.
		No	Go to the next step.
5	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - Switch the ignition to ON (Engine off). - Measure voltage between MAF/IAT sensor terminal F (wiring harness-side) and body ground. - Is voltage B+?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR FOR POOR CONNECTION - Switch the ignition to off. - Disconnect the PCM connector. - Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). - Are there any malfunction?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
7	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR OPEN CIRCUIT - Inspect continuity between MAF/IAT sensor terminal F (wiring harness-side) and PCM terminal 1P (wiring harness-side). - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace suspected part, then go to Step 9.
8	INSPECT IAT SENSOR GROUND CIRCUIT FOR OPEN CIRCUIT - Inspect continuity between MAF/IAT sensor terminal E (wiring harness-side) and PCM terminal 1AT (wiring harness-side). - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace suspected part, then go to the next step.
9	VERIFY TROUBLESHOOTING OF DTC P0113:00 HAS BEEN COMPLETED Verify that all disconnected connectors reconnected.	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the PCM.


	• Switch the ignition to ON (Engine off). • Clear the DTC from the PCM memory using the M-MDS. • Start engine and warm it up completely. • Is same DTC present?		(See PCM REMOVAL/ INSTALLATION [MZI 3.7 V6] .) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [MZI 3.7 V6].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [MZI 3.7 V6] .)
		No	Troubleshooting completed.

2012 - Mazda6 - Engine


DTC P0113:00 [MZI 3.7 V6]

DTC P0113:00	IAT sensor circuit high input
DETECTION CONDITION	Indicates the sensor signal is more than the self-test maximum. The IAT sensor maximum is 4.6 V or –50 °C { –58 °F } .
POSSI BLE CAUSE	- Connector or terminal malfunction - IAT sensor malfunction - Short to power supply between MAF/IAT sensor terminal F and PCM terminal 1P - Open circuit between MAF/IAT sensor terminal F and PCM terminal 1P - Open circuit between MAF/IAT sensor terminal E and PCM terminal 1AT

IAT SENSOR (MAF/IAT SENSOR)







PCM



PCM WIRING HARNESS-SIDE CONNECTOR

MAF/IAT SENSOR WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED Has FREEZE FRAME DATA been recorded?	Yes Go to the next step.
		No Record FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related Service Bulletins available?	Yes Perform repair or diagnosis according to the available Service Bulletins. If the vehicle is not repaired, go to the next step.
		No Go to the next step.

3	INSPECT IAT SENSOR CONNECTOR FOR POOR CONNECTION - Switch the ignition to off. - Disconnect MAF/IAT sensor connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Are there any malfunction?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
4	CLASSIFY IAT SENSOR MALFUNCTION OR HARNESS MALFUNCTION - Disconnect the MAF/IAT sensor connector. - Switch the ignition to ON (Engine off). - Measure voltage between MAF/IAT sensor terminal F (wiring harness-side) and body ground. - Is voltage 4.5—5.5 V?	Yes	Inspect the IAT sensor. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [MZI 3.7 V6] .) Replace if necessary, then go to Step 9.
		No	Go to the next step.
5	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - Switch the ignition to ON (Engine off). - Measure voltage between MAF/IAT sensor terminal F (wiring harness-side) and body ground. - Is voltage B+ ?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR FOR POOR CONNECTION - Switch the ignition to off. - Disconnect the PCM connector. - Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). - Are there any malfunction?	Yes	Repair or replace suspected part, then go to Step 9.
		No	Go to the next step.
7	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR OPEN CIRCUIT - Inspect continuity between MAF/IAT sensor terminal F (wiring harness-side) and PCM terminal 1P (wiring harness-side). - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace suspected part, then go to Step 9.
8	INSPECT IAT SENSOR GROUND CIRCUIT FOR OPEN CIRCUIT - Inspect continuity between MAF/IAT sensor terminal E (wiring harness-side) and PCM terminal 1AT (wiring harness-side). - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace suspected part, then go to the next step.
9	VERIFY TROUBLESHOOTING OF DTC P0113:00 HAS BEEN COMPLETED Verify that all disconnected connectors reconnected.	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the PCM.

	• Switch the ignition to ON (Engine off). • Clear the DTC from the PCM memory using the M-MDS. • Start engine and warm it up completely. • Is same DTC present?		(See PCM REMOVAL/ INSTALLATION [MZI 3.7 V6] .) Go to the next step.
		No	Go to the next step.
10	VERI FY AFTER REPAI R PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAI R PROCEDURE [MZI 3.7 V6] .) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [MZI 3.7 V6] .)
		No	Troubleshooting completed.