


2012 - Mazda6 - Engine

DTC P0108:00 [MZR 2.5]

DTC P0108:00	MAP sensor circuit high input
DETECT I O N C O N D I T I O N	- The PCM monitors the input voltage from the MAP sensor. If input the voltage is above 4.9 V for 5 s, the PCM determines that the MAP sensor circuit has a malfunction. Diagnostic support note - This is a continuous monitor (CCM). - The MIL illuminates if the PCM detects the above malfunction condition during first drive cycle. - FREEZE FRAME DATA (Mode 2)/Snapshot data is available. - The DTC is stored in the PCM memory.
P O S S I B L E C A U S E	- MAP sensor connector or terminal malfunction - PCM connector or terminal malfunction - Short circuit in MAP sensor signal circuit and power supply circuit each other - Short to power supply in wiring harness between MAP sensor terminal D and PCM terminal 2AG - Open circuit in wiring harness between MAP sensor terminal A and PCM terminal 2AV - Open circuit in wiring harness between MAP sensor terminal D and PCM terminal 2AG - MAP sensor malfunction - PCM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT MAP SENSOR CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the MAP sensor connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the terminal and/or connector, then go to Step 9.
		No Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION	Yes Repair or replace the terminal and/or connector, then


	Disconnect the PCM connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	go to Step 9. No Go to the next step.
5	INSPECT MAP SENSOR SIGNAL AND POWER SUPPLY CIRCUITS FOR SHORT EACH OTHER - MAP sensor and PCM connectors are disconnected. - Inspect for continuity between MAP sensor terminals C and D (wiring harness-side). - Is there continuity?	Yes Repair or replace the malfunctioning wiring harness, then go to Step 9. No Go to the next step.
6	INSPECT MAP SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - MAP sensor and PCM connectors are disconnected. - Switch the ignition to ON (engine off). - Measure the voltage between MAP sensor terminal D (wiring harness-side) and body ground. - Is there any voltage?	Yes Repair or replace the wiring harness for a possible short to power supply, then go to Step 9. No Go to the next step.
7	INSPECT MAP SENSOR CIRCUIT FOR OPEN CIRCUIT - MAP sensor and PCM connectors are disconnected. - Switch the ignition to off. - Inspect for continuity between the following terminals: - MAP sensor terminal A (wiring harness-side) and PCM terminal 2AV (wiring harness-side) - MAP sensor terminal D (wiring harness-side) and PCM terminal 2AG (wiring harness-side) - Is there continuity?	Yes Go to the next step. No Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT MAP SENSOR - Reconnect all disconnected connectors. - Inspect the MAP sensor. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [MZR 2.5].) - Is there any malfunction?	Yes Replace the MAP sensor, then go to the next step. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR REMOVAL/ INSTALLATION [MZR 2.5].) No Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [MZR 2.5].) - Perform the KOEO or KOER self test.	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the PCM. (See PCM REMOVAL/ INSTALLATION [MZR 2.5].) Go to the next step.

	(See KOE0/ KOER SELF TEST [MZR 2.5] .)	No	Go to the next step.
	• Is the same DTC present?		
10	VERIFY AFTER REPAIR PROCEDURE	Yes	Go to the applicable DTC inspection.
	• Perform the "AFTER REPAIR PROCEDURE".		(See DTC TABLE [MZR 2.5] .)
	(See AFTER REPAIR PROCEDURE [MZR 2.5] .)		
	• Are any DTCs present?	No	DTC troubleshooting completed.

2012 - Mazda6 - Engine

DTC P0108:00 [MZR 2.5]

DTC P0108:00	MAP sensor circuit high input
DETECT I O N C O N D I T I O N	- The PCM monitors the input voltage from the MAP sensor. If input the voltage is above 4.9 V for 5 s, the PCM determines that the MAP sensor circuit has a malfunction. Diagnostic support note - This is a continuous monitor (CCM). - The MIL illuminates if the PCM detects the above malfunction condition during first drive cycle. - FREEZE FRAME DATA (Mode 2)/Snapshot data is available. - The DTC is stored in the PCM memory.
P O S S I B L E C A U S E	- MAP sensor connector or terminal malfunction - PCM connector or terminal malfunction - Short circuit in MAP sensor signal circuit and power supply circuit each other - Short to power supply in wiring harness between MAP sensor terminal D and PCM terminal 2AG - Open circuit in wiring harness between MAP sensor terminal A and PCM terminal 2AV - Open circuit in wiring harness between MAP sensor terminal D and PCM terminal 2AG - MAP sensor malfunction - PCM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT MAP SENSOR CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the MAP sensor connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the terminal and/or connector, then go to Step 9.
		No Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION	Yes Repair or replace the terminal and/or connector, then

	Disconnect the PCM connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	go to Step 9. No Go to the next step.
5	INSPECT MAP SENSOR SIGNAL AND POWER SUPPLY CIRCUITS FOR SHORT EACH OTHER - MAP sensor and PCM connectors are disconnected. - Inspect for continuity between MAP sensor terminals C and D (wiring harness-side). - Is there continuity?	Yes Repair or replace the malfunctioning wiring harness, then go to Step 9. No Go to the next step.
6	INSPECT MAP SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - MAP sensor and PCM connectors are disconnected. - Switch the ignition to ON (engine off). - Measure the voltage between MAP sensor terminal D (wiring harness-side) and body ground. - Is there any voltage?	Yes Repair or replace the wiring harness for a possible short to power supply, then go to Step 9. No Go to the next step.
7	INSPECT MAP SENSOR CIRCUIT FOR OPEN CIRCUIT - MAP sensor and PCM connectors are disconnected. - Switch the ignition to off. - Inspect for continuity between the following terminals: - MAP sensor terminal A (wiring harness-side) and PCM terminal 2AV (wiring harness-side) - MAP sensor terminal D (wiring harness-side) and PCM terminal 2AG (wiring harness-side) - Is there continuity?	Yes Go to the next step. No Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT MAP SENSOR - Reconnect all disconnected connectors. - Inspect the MAP sensor. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [MZR 2.5].) - Is there any malfunction?	Yes Replace the MAP sensor, then go to the next step. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR REMOVAL/ INSTALLATION [MZR 2.5].) No Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [MZR 2.5].) - Perform the KOEO or KOER self test.	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the PCM. (See PCM REMOVAL/ INSTALLATION [MZR 2.5].) Go to the next step.

	(See KOE0/ KOER SELF TEST [MZR 2.5] .) • Is the same DTC present?	No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [MZR 2.5] .) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [MZR 2.5] .)
		No	DTC troubleshooting completed.