

2012 - Mazda6 - Engine


DTC P0132:00 [MZR 2.5]

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DTC<br>P0132:00        | A/F sensor circuit high input                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| DETECTION<br>CONDITION | <ul style="list-style-type: none"><li>The PCM monitors the input voltage from the A/F sensor when the engine is running. If the input voltage is <b>above battery voltage–1.2 V for 1 s</b>, the PCM determines that the A/F sensor circuit voltage is high.</li></ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"><li>This is a continuous monitor (A/F sensor, HO2S).</li><li>The MIL illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM.</li><li>PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle.</li><li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li><li>The DTC is stored in the PCM memory.</li></ul> |
| POSSIBLE<br>CAUSE      | <ul style="list-style-type: none"><li>A/F sensor connector or terminal malfunction</li><li>PCM connector or terminal malfunction</li><li>Short to power supply in wiring harness between A/F sensor terminal B and PCM terminal 2AD</li><li>Short to power supply in wiring harness between A/F sensor terminal D and PCM terminal 2AC</li><li>Short to power supply in wiring harness between A/F sensor terminal F and PCM terminal 2Z</li><li>A/F sensor malfunction</li><li>PCM malfunction</li></ul>                                                                                                                                                                                                                                                                                                                                            |
|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

MAIN RELAY  
TERMINAL D




A/F SENSOR

PCM



A/F SENSOR  
WIRING HARNESS-SIDE  
CONNECTOR

PCM WIRING HARNESS-SIDE CONNECTOR



## Diagnostic procedure

| STEP | INSPECTION                                                                                                                                                                                                                                                                                             | ACTION                                                                                                                                                                       |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <b>IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2)</b> <ul style="list-style-type: none"> <li>Is the DTC P0132:00 on FREEZE FRAME DATA (Mode 2)?</li> </ul>                                                                                                                                        | Yes Go to the next step.<br><br>No Go to troubleshooting procedures for DTC on FREEZE FRAME DATA (Mode 2).<br>(See <a href="#">DTC TABLE [MZR 2.5]</a> .)                    |
| 2    | <b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Have the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor, HO2S related) been recorded?</li> </ul> | Yes Go to the next step.<br><br>No Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step. |
| 3    | <b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>                                                         | Yes Perform repair or diagnosis according to the available repair information.<br><br>• If the vehicle is not repaired, go to the next step.<br><br>No Go to the next step.  |
| 4    | <b>VERIFY RELATED PENDING OR STORED DTC</b>                                                                                                                                                                                                                                                            | Yes Go to the applicable DTC inspection.                                                                                                                                     |

|   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                  |                                |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
|   | <ul style="list-style-type: none"> <li>Switch the ignition to off, then to the ON (engine off).</li> <li>Verify the pending code or stored DTCs using the M-MDS.</li> </ul> <p>(See <b>ON-BOARD DIAGNOSTIC TEST [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Are any other DTCs present?</li> </ul>                                                                                                                                                                                                                     | <p>(See <b>DTC TABLE [MZR 2.5]</b>.)</p>                                                                                                                                                                                         |                                |
| 5 | <b>INSPECT A/ F SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the A/F sensor connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                                      | <p>Yes Repair or replace the terminal and/or connector, then go to Step 9.</p>                                                                                                                                                   | <p>No Go to the next step.</p> |
| 6 | <b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                                                                                          | <p>Yes Repair or replace the terminal and/or connector, then go to Step 9.</p>                                                                                                                                                   | <p>No Go to the next step.</p> |
| 7 | <b>INSPECT A/ F SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>A/F sensor and PCM connectors are disconnected.</li> <li>Switch the ignition to ON (engine off).</li> <li>Measure the voltage between the following terminals and body ground: <ul style="list-style-type: none"> <li>A/F sensor terminal B (wiring harness-side)</li> <li>A/F sensor terminal D (wiring harness-side)</li> <li>A/F sensor terminal F (wiring harness-side)</li> </ul> </li> <li>Is there any voltage?</li> </ul> | <p>Yes Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.</p>                                                                                                                         | <p>No Go to the next step.</p> |
| 8 | <b>INSPECT A/ F SENSOR</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the A/F sensor.</li> </ul> <p>(See <b>AIR FUEL RATIO (A/ F) SENSOR INSPECTION [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                               | <p>Yes Replace the A/F sensor, then go to the next step.</p> <p>(See <b>AIR FUEL RATIO (A/ F) SENSOR REMOVAL/ INSTALLATION [MZR 2.5]</b>.)</p>                                                                                   | <p>No Go to the next step.</p> |
| 9 | <b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Make sure to reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS.</li> </ul> <p>(See <b>AFTER REPAIR PROCEDURE [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Perform the KOEO or KOER self test.</li> </ul> <p>(See <b>KOEO/ KOER SELF TEST [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Is the PENDING CODE for this DTC present?</li> </ul>                             | <p>Yes Repeat the inspection from Step 1.</p> <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM.</li> </ul> <p>(See <b>PCM REMOVAL/ INSTALLATION [MZR 2.5]</b>.)</p> <p>Go to the next step.</p> | <p>No Go to the next step.</p> |


|    |                                                                                                                                                                                                                     |     |                                                                             |
|----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------|
| 10 | <b>VERI FY AFTER REPAI R PROCEDURE</b> <ul style="list-style-type: none"><li>• Perform the “AFTER REPAIR PROCEDURE”.<br/>(See <b>AFTER REPAI R PROCEDURE [ MZR 2.5]</b>.)</li><li>• Are any DTCs present?</li></ul> | Yes | Go to the applicable DTC inspection.<br>(See <b>DTC TABLE [ MZR 2.5]</b> .) |
|    |                                                                                                                                                                                                                     | No  | DTC troubleshooting completed.                                              |

2012 - Mazda6 - Engine



DTC P0132:00 [MZR 2.5]

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DTC<br>P0132:00        | A/F sensor circuit high input                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| DETECTION<br>CONDITION | <ul style="list-style-type: none"><li>The PCM monitors the input voltage from the A/F sensor when the engine is running. If the input voltage is <b>above battery voltage–1.2 V for 1 s</b>, the PCM determines that the A/F sensor circuit voltage is high.</li></ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"><li>This is a continuous monitor (A/F sensor, HO2S).</li><li>The MIL illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM.</li><li>PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle.</li><li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li><li>The DTC is stored in the PCM memory.</li></ul> |
| POSSIBLE<br>CAUSE      | <ul style="list-style-type: none"><li>A/F sensor connector or terminal malfunction</li><li>PCM connector or terminal malfunction</li><li>Short to power supply in wiring harness between A/F sensor terminal B and PCM terminal 2AD</li><li>Short to power supply in wiring harness between A/F sensor terminal D and PCM terminal 2AC</li><li>Short to power supply in wiring harness between A/F sensor terminal F and PCM terminal 2Z</li><li>A/F sensor malfunction</li><li>PCM malfunction</li></ul>                                                                                                                                                                                                                                                                                                                                            |
|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |



MAIN RELAY  
TERMINAL D



A/F SENSOR  
WIRING HARNESS-SIDE  
CONNECTOR



PCM WIRING HARNESS-SIDE CONNECTOR



## Diagnostic procedure

| STEP | INSPECTION                                                                                                                                                                                                                                                                                             | ACTION                                                                                                                                                                                                                      |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <b>IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2)</b> <ul style="list-style-type: none"> <li>Is the DTC P0132:00 on FREEZE FRAME DATA (Mode 2)?</li> </ul>                                                                                                                                        | <p>Yes Go to the next step.</p> <p>No Go to troubleshooting procedures for DTC on FREEZE FRAME DATA (Mode 2).<br/>(See <a href="#">DTC TABLE [MZR 2.5]</a>.)</p>                                                            |
| 2    | <b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Have the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor, HO2S related) been recorded?</li> </ul> | <p>Yes Go to the next step.</p> <p>No Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.</p>                                         |
| 3    | <b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>                                                         | <p>Yes Perform repair or diagnosis according to the available repair information.</p> <ul style="list-style-type: none"> <li>If the vehicle is not repaired, go to the next step.</li> </ul> <p>No Go to the next step.</p> |
| 4    | <b>VERIFY RELATED PENDING OR STORED DTC</b>                                                                                                                                                                                                                                                            | <p>Yes Go to the applicable DTC inspection.</p>                                                                                                                                                                             |

|   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                  |                         |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
|   | <ul style="list-style-type: none"> <li>Switch the ignition to off, then to the ON (engine off).</li> <li>Verify the pending code or stored DTCs using the M-MDS.</li> </ul> <p>(See <b>ON-BOARD DIAGNOSTIC TEST [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Are any other DTCs present?</li> </ul>                                                                                                                                                                                                                     | <p>(See <b>DTC TABLE [MZR 2.5]</b>.)</p>                                                                                                                                                                                         |                         |
| 5 | <b>INSPECT A/ F SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the A/F sensor connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                                      | <p>Yes Repair or replace the terminal and/or connector, then go to Step 9.</p>                                                                                                                                                   | No Go to the next step. |
| 6 | <b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                                                                                          | <p>Yes Repair or replace the terminal and/or connector, then go to Step 9.</p>                                                                                                                                                   | No Go to the next step. |
| 7 | <b>INSPECT A/ F SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>A/F sensor and PCM connectors are disconnected.</li> <li>Switch the ignition to ON (engine off).</li> <li>Measure the voltage between the following terminals and body ground: <ul style="list-style-type: none"> <li>A/F sensor terminal B (wiring harness-side)</li> <li>A/F sensor terminal D (wiring harness-side)</li> <li>A/F sensor terminal F (wiring harness-side)</li> </ul> </li> <li>Is there any voltage?</li> </ul> | <p>Yes Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.</p>                                                                                                                         | No Go to the next step. |
| 8 | <b>INSPECT A/ F SENSOR</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the A/F sensor.</li> </ul> <p>(See <b>AIR FUEL RATIO (A/ F) SENSOR INSPECTION [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Is there any malfunction?</li> </ul>                                                                                                                                                                                                                               | <p>Yes Replace the A/F sensor, then go to the next step.</p> <p>(See <b>AIR FUEL RATIO (A/ F) SENSOR REMOVAL/ INSTALLATION [MZR 2.5]</b>.)</p>                                                                                   | No Go to the next step. |
| 9 | <b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Make sure to reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS.</li> </ul> <p>(See <b>AFTER REPAIR PROCEDURE [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Perform the KOEO or KOER self test.</li> </ul> <p>(See <b>KOEO/ KOER SELF TEST [MZR 2.5]</b>.)</p> <ul style="list-style-type: none"> <li>Is the PENDING CODE for this DTC present?</li> </ul>                             | <p>Yes Repeat the inspection from Step 1.</p> <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM.</li> </ul> <p>(See <b>PCM REMOVAL/ INSTALLATION [MZR 2.5]</b>.)</p> <p>Go to the next step.</p> | No Go to the next step. |

|    |                                                                                                                                                                                                                     |     |                                                                             |
|----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------|
| 10 | <b>VERI FY AFTER REPAI R PROCEDURE</b> <ul style="list-style-type: none"><li>• Perform the “AFTER REPAIR PROCEDURE”.<br/>(See <b>AFTER REPAI R PROCEDURE [ MZR 2.5]</b>.)</li><li>• Are any DTCs present?</li></ul> | Yes | Go to the applicable DTC inspection.<br>(See <b>DTC TABLE [ MZR 2.5]</b> .) |
|    |                                                                                                                                                                                                                     | No  | DTC troubleshooting completed.                                              |