


2012 - Mazda6 - Brakes

DTC C0031:01 / C0031:13 / C0034:01 / C0034:13 / C0037:01 / C0037:13 / C003A:01 / C003A:13
[DYNAMIC STABILITY CONTROL (DSC)]

C0031:01	LF ABS wheel-speed sensor
C0031:13	
C0034:01	RF ABS wheel-speed sensor
C0034:13	
C0037:01	LR ABS wheel-speed sensor
C0037:13	
C003A:01	RR ABS wheel-speed sensor
C003A:13	
DETECTION CONDITION	C0031:01 / C0034:01 / C0037:01 / C003A:01 • Detects a drop in the power supply voltage ON signal from the ABS wheel-speed sensor for a continuous 0.53 s. C0031:13 / C0034:13 / C0037:13 / C003A:13 • Detect the signal of open circuit for 0.53 s from the ABS wheel-speed sensor.
	• Connector or terminal malfunction • Short to ground in wiring harness between following terminals: ▪ LF ABS wheel-speed sensor terminal A and DSC HU/CM terminal S ▪ LF ABS wheel-speed sensor terminal B and DSC HU/CM terminal P ▪ RF ABS wheel-speed sensor terminal A and DSC HU/CM terminal R ▪ RF ABS wheel-speed sensor terminal B and DSC HU/CM terminal O

**POSSIBLE
CAUSE**

- LR ABS wheel-speed sensor terminal A and DSC HU/CM terminal L
- LR ABS wheel-speed sensor terminal B and DSC HU/CM terminal I
- RR ABS wheel-speed sensor terminal A and DSC HU/CM terminal M
- RR ABS wheel-speed sensor terminal B and DSC HU/CM terminal J
- Open circuit in wiring harness between following terminals:
 - LF ABS wheel-speed sensor terminal A and DSC HU/CM terminal S
 - LF ABS wheel-speed sensor terminal B and DSC HU/CM terminal P
 - RF ABS wheel-speed sensor terminal A and DSC HU/CM terminal R
 - RF ABS wheel-speed sensor terminal B and DSC HU/CM terminal O
 - LR ABS wheel-speed sensor terminal A and DSC HU/CM terminal L
 - LR ABS wheel-speed sensor terminal B and DSC HU/CM terminal I
 - RR ABS wheel-speed sensor terminal A and DSC HU/CM terminal M
 - RR ABS wheel-speed sensor terminal B and DSC HU/CM terminal J
- ABS wheel-speed sensor malfunction
- DSC HU/CM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
	INSPECT ABS WHEEL-SPEED SENSOR CONNECTOR	

1	CONDITION	Yes Repair or replace the connector or terminals, then go to Step 5.
	• Switch the ignition to off. • Disconnect the negative battery cable. • Disconnect the following connector: ▪ C0031:01/C0031:13 • LF ABS wheel-speed sensor ▪ C0034:01/C0034:13 • RF ABS wheel-speed sensor ▪ C0037:01/C0037:13 • LR ABS wheel-speed sensor ▪ C003A:01/C003A:13 • RR ABS wheel-speed sensor • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	No Go to the next step.
2	INSPECT DSC HU/ CM CONNECTOR CONDITION • Disconnect the DSC HU/CM connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 5. No C0031:01/C0034:01/C0037:01/C003A:01 • Go to the next step. C0031:13/C0034:13/C0037:13/C003A:13 • Go to Step 4.
3	INSPECT ABS WHEEL-SPEED SENSOR CIRCUIT FOR SHORT TO GROUND • Inspect for continuity between the following terminals and body ground: ▪ C0031:01 • LF ABS	Yes Repair or replace the wiring harness for a possible short to ground, then go to Step 5. No Go to the next step.

wheel-
speed
sensor
terminal
A
(wiring
harness-
side)

- LF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)

▪ C0034:01

- RF ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
- RF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)

▪ C0037:01

- LR ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
- LR ABS
wheel-
speed
sensor
terminal
B

	(wiring harness-side) ▪ C003A:01 • RR ABS wheel-speed sensor terminal A (wiring harness-side) • RR ABS wheel-speed sensor terminal B (wiring harness-side) • Is there continuity?		
4	INSPECT ABS WHEEL-SPEED SENSOR CIRCUIT FOR OPEN CIRCUIT • Inspect for continuity between the following terminals: ▪ C0031:13 • LF ABS wheel-speed sensor terminal A (wiring harness-side) and DSC HU/CM terminal S (wiring harness-side) • LF ABS wheel-speed sensor terminal B and DSC	Yes Replace the malfunctioning ABS wheel-speed sensor, then go to the next step. (See FRONT ABS WHEEL-SPEED SENSOR REMOVAL/ INSTALLATION.) (See REAR ABS WHEEL-SPEED SENSOR REMOVAL/ INSTALLATION.)	No Repair or replace the wiring harness for a possible open circuit, then go to the next step.

HU/CM
terminal
P
(wiring
harness-
side)

▪ C0034:13

- RF ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
and DSC
HU/CM
terminal
R
(wiring
harness-
side)
- RF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)
and DSC
HU/CM
terminal
O
(wiring
harness-
side)

▪ C0037:13

- LR ABS
wheel-
speed
sensor
terminal
A and
DSC
HU/CM
terminal
L (wiring
harness-
side)
- LR ABS

	wheel-speed sensor terminal B (wiring harness-side) and DSC HU/CM terminal I (wiring harness-side) ▪ C003A:13 • RR ABS wheel-speed sensor terminal A (wiring harness-side) and DSC HU/CM terminal M (wiring harness-side) • RR ABS wheel-speed sensor terminal B (wiring harness-side) and DSC HU/CM terminal J (wiring harness-side) • Is there continuity?		
5	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect the disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the DSC HU/CM	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)

	memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		No	Go to the next step.
6	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?		Yes	Go to the applicable DTC inspection.
			No	DTC troubleshooting completed.


2012 - Mazda6 - Brakes

DTC C0031:01 / C0031:13 / C0034:01 / C0034:13 / C0037:01 / C0037:13 / C003A:01 / C003A:13
[DYNAMIC STABILITY CONTROL (DSC)]

C0031:01	LF ABS wheel-speed sensor
C0031:13	
C0034:01	RF ABS wheel-speed sensor
C0034:13	
C0037:01	LR ABS wheel-speed sensor
C0037:13	
C003A:01	RR ABS wheel-speed sensor
C003A:13	
DETECTION CONDITION	C0031:01 / C0034:01 / C0037:01 / C003A:01 • Detects a drop in the power supply voltage ON signal from the ABS wheel-speed sensor for a continuous 0.53 s. C0031:13 / C0034:13 / C0037:13 / C003A:13 • Detect the signal of open circuit for 0.53 s from the ABS wheel-speed sensor.
	• Connector or terminal malfunction • Short to ground in wiring harness between following terminals: ▪ LF ABS wheel-speed sensor terminal A and DSC HU/CM terminal S ▪ LF ABS wheel-speed sensor terminal B and DSC HU/CM terminal P ▪ RF ABS wheel-speed sensor terminal A and DSC HU/CM terminal R ▪ RF ABS wheel-speed sensor terminal B and DSC HU/CM terminal O

**POSSIBLE
CAUSE**

- LR ABS wheel-speed sensor terminal A and DSC HU/CM terminal L
- LR ABS wheel-speed sensor terminal B and DSC HU/CM terminal I
- RR ABS wheel-speed sensor terminal A and DSC HU/CM terminal M
- RR ABS wheel-speed sensor terminal B and DSC HU/CM terminal J
- Open circuit in wiring harness between following terminals:
 - LF ABS wheel-speed sensor terminal A and DSC HU/CM terminal S
 - LF ABS wheel-speed sensor terminal B and DSC HU/CM terminal P
 - RF ABS wheel-speed sensor terminal A and DSC HU/CM terminal R
 - RF ABS wheel-speed sensor terminal B and DSC HU/CM terminal O
 - LR ABS wheel-speed sensor terminal A and DSC HU/CM terminal L
 - LR ABS wheel-speed sensor terminal B and DSC HU/CM terminal I
 - RR ABS wheel-speed sensor terminal A and DSC HU/CM terminal M
 - RR ABS wheel-speed sensor terminal B and DSC HU/CM terminal J
- ABS wheel-speed sensor malfunction
- DSC HU/CM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
	INSPECT ABS WHEEL-SPEED SENSOR CONNECTOR	

1	CONDITION	Yes Repair or replace the connector or terminals, then go to Step 5.
	• Switch the ignition to off. • Disconnect the negative battery cable. • Disconnect the following connector: ▪ C0031:01/C0031:13 • LF ABS wheel-speed sensor ▪ C0034:01/C0034:13 • RF ABS wheel-speed sensor ▪ C0037:01/C0037:13 • LR ABS wheel-speed sensor ▪ C003A:01/C003A:13 • RR ABS wheel-speed sensor • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	No Go to the next step.
2	INSPECT DSC HU/ CM CONNECTOR CONDITION • Disconnect the DSC HU/CM connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 5. No C0031:01/C0034:01/C0037:01/C003A:01 • Go to the next step. C0031:13/C0034:13/C0037:13/C003A:13 • Go to Step 4.
3	INSPECT ABS WHEEL-SPEED SENSOR CIRCUIT FOR SHORT TO GROUND • Inspect for continuity between the following terminals and body ground: ▪ C0031:01 • LF ABS	Yes Repair or replace the wiring harness for a possible short to ground, then go to Step 5. No Go to the next step.

wheel-
speed
sensor
terminal
A
(wiring
harness-
side)

- LF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)

▪ C0034:01

- RF ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
- RF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)

▪ C0037:01

- LR ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
- LR ABS
wheel-
speed
sensor
terminal
B

	(wiring harness-side) ▪ C003A:01 • RR ABS wheel-speed sensor terminal A (wiring harness-side) • RR ABS wheel-speed sensor terminal B (wiring harness-side) • Is there continuity?		
4	INSPECT ABS WHEEL-SPEED SENSOR CIRCUIT FOR OPEN CIRCUIT • Inspect for continuity between the following terminals: ▪ C0031:13 • LF ABS wheel-speed sensor terminal A (wiring harness-side) and DSC HU/CM terminal S (wiring harness-side) • LF ABS wheel-speed sensor terminal B and DSC	Yes	Replace the malfunctioning ABS wheel-speed sensor, then go to the next step. (See FRONT ABS WHEEL-SPEED SENSOR REMOVAL/ INSTALLATION.) (See REAR ABS WHEEL-SPEED SENSOR REMOVAL/ INSTALLATION.)
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.

HU/CM
terminal
P
(wiring
harness-
side)

▪ C0034:13

- RF ABS
wheel-
speed
sensor
terminal
A
(wiring
harness-
side)
and DSC
HU/CM
terminal
R
(wiring
harness-
side)
- RF ABS
wheel-
speed
sensor
terminal
B
(wiring
harness-
side)
and DSC
HU/CM
terminal
O
(wiring
harness-
side)

▪ C0037:13

- LR ABS
wheel-
speed
sensor
terminal
A and
DSC
HU/CM
terminal
L (wiring
harness-
side)
- LR ABS

	wheel-speed sensor terminal B (wiring harness-side) and DSC HU/CM terminal I (wiring harness-side) ▪ C003A:13 • RR ABS wheel-speed sensor terminal A (wiring harness-side) and DSC HU/CM terminal M (wiring harness-side) • RR ABS wheel-speed sensor terminal B (wiring harness-side) and DSC HU/CM terminal J (wiring harness-side) • Is there continuity?		
5	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect the disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the DSC HU/CM	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)

	memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		No	Go to the next step.
6	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?		Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)] .)
			No	DTC troubleshooting completed.