


2012 - Mazda6 - Brakes

DTC C0040:13/ C0040:64 [DYNAMIC STABILITY CONTROL (DSC)]

C0040:13	Brake switch
C0040:64	
DETECTION CONDI TION	C0040:13 • Detect the open circuit in brake switch circuit for 0.3 s. C0040:64 • Detect brake switch ON signal for 15 min or more when driving at vehicle speed of 15 km/ h { 9.3 mph} or more.
POSSI BLE CAUSE	• STOP 10 A fuse malfunction • Connector or terminal malfunction • Short to ground or open circuit in wiring harness between brake switch terminal A and battery positive terminal • Open circuit in wiring harness between brake switch terminal D and DSC HU/CM terminal C • Short to power supply in wiring harness between brake switch terminal D and DSC HU/CM terminal C • Brake switch malfunction • DSC HU/CM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY PID FOR BRAKE SWITCH MALFUNCTION - Connect the M-MDS to the DLC-2. - Access the BRAKE_SW PID using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Is the brake switch operation normal?	Yes Go to Step 11. No The PID value is continuously On whether the brake pedal is depressed or not. - Go to Step 8. The PID value is continuously Off whether the brake pedal is depressed or not. - Go to the next step.
2	INSPECT FUSE	Yes Replace the fuse, then go to Step 11.

	• Switch the ignition to off. • Disconnect the negative battery cable. • Remove the STOP 10 A fuse. • Inspect the fuse. • Is there any malfunction?	No	Install the fuse, then go to the next step.
3	INSPECT BRAKE SWITCH POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT • Reconnect the negative battery cable. • Measure the voltage between brake switch terminal A (wiring harness-side) and body ground. • Is the voltage B+ ?	Yes	Go to Step 5.
		No	Go to the next step.
4	INSPECT BRAKE SWITCH CONNECTOR CONDITION • Disconnect the negative battery cable. • Disconnect the brake switch connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes	Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Repair or replace the wiring harness for a possible short to ground or open circuit. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
5	INSPECT DSC HU/ CM CONNECTOR CONDITION • Disconnect the negative battery cable. • Disconnect the DSC HU/CM connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 11.
		No	Go to the next step.
6	INSPECT BRAKE SWITCH SIGNAL CIRCUIT FOR OPEN CIRCUIT • Inspect for continuity between brake switch terminal D (wiring harness-side) and DSC HU/CM terminal C (wiring harness-side). • Is there continuity?	Yes	Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Go to the next step.
7	INSPECT BRAKE SWITCH CONNECTOR CONDITION • Disconnect the brake switch connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection).	Yes	Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11.


	Is there any malfunction?	(See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No Repair or replace the wiring harness for a possible short to ground or open circuit. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
8	INSPECT DSC HU/ CM CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the DSC HU/CM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 11. No Go to the next step.
9	INSPECT BRAKE SWITCH CONNECTOR CONDITION - Disconnect the brake switch connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.) No Go to the next step.
10	INSPECT BRAKE SWITCH SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - Reconnect the negative battery cable. - Measure the voltage between DSC HU/CM terminal C (wiring harness-side) and body ground. - Is the voltage B+ ?	Yes Repair or replace the wiring harness for a possible short to power supply. Replace the brake switch, then go to the next step. (See BRAKE PEDAL REMOVAL/ INSTALLATION.) No Replace the brake switch, then go to the next step. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
11	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect the disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the DSC HU/CM memory using the M-MDS.	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)

	(See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Drive the vehicle at speed of 15 km/ h { 9.3 mph} or more. • Gradually slow down and stop the vehicle. • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?	No	Go to the next step.
12	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)] .)
		No	DTC troubleshooting completed.

2012 - Mazda6 - Brakes

DTC C0040:13/ C0040:64 [DYNAMIC STABILITY CONTROL (DSC)]

C0040:13	Brake switch
C0040:64	
DETECTION CONDI TION	C0040:13 • Detect the open circuit in brake switch circuit for 0.3 s. C0040:64 • Detect brake switch ON signal for 15 min or more when driving at vehicle speed of 15 km/ h { 9.3 mph} or more.
POSSI BLE CAUSE	• STOP 10 A fuse malfunction • Connector or terminal malfunction • Short to ground or open circuit in wiring harness between brake switch terminal A and battery positive terminal • Open circuit in wiring harness between brake switch terminal D and DSC HU/CM terminal C • Short to power supply in wiring harness between brake switch terminal D and DSC HU/CM terminal C • Brake switch malfunction • DSC HU/CM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY PID FOR BRAKE SWITCH MALFUNCTION - Connect the M-MDS to the DLC-2. - Access the BRAKE_SW PID using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Is the brake switch operation normal?	Yes Go to Step 11. No The PID value is continuously On whether the brake pedal is depressed or not. - Go to Step 8. The PID value is continuously Off whether the brake pedal is depressed or not. - Go to the next step.
2	INSPECT FUSE	Yes Replace the fuse, then go to Step 11.

	• Switch the ignition to off. • Disconnect the negative battery cable. • Remove the STOP 10 A fuse. • Inspect the fuse. • Is there any malfunction?	No	Install the fuse, then go to the next step.
3	INSPECT BRAKE SWITCH POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT • Reconnect the negative battery cable. • Measure the voltage between brake switch terminal A (wiring harness-side) and body ground. • Is the voltage B+ ?	Yes	Go to Step 5.
		No	Go to the next step.
4	INSPECT BRAKE SWITCH CONNECTOR CONDITION • Disconnect the negative battery cable. • Disconnect the brake switch connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes	Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Repair or replace the wiring harness for a possible short to ground or open circuit. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
5	INSPECT DSC HU/ CM CONNECTOR CONDITION • Disconnect the negative battery cable. • Disconnect the DSC HU/CM connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection). • Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 11.
		No	Go to the next step.
6	INSPECT BRAKE SWITCH SIGNAL CIRCUIT FOR OPEN CIRCUIT • Inspect for continuity between brake switch terminal D (wiring harness-side) and DSC HU/CM terminal C (wiring harness-side). • Is there continuity?	Yes	Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Go to the next step.
7	INSPECT BRAKE SWITCH CONNECTOR CONDITION • Disconnect the brake switch connector. • Inspect the connector and terminals (corrosion, damage, pin disconnection).	Yes	Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11.

	Is there any malfunction?	(See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No Repair or replace the wiring harness for a possible short to ground or open circuit. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
8	INSPECT DSC HU/ CM CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the DSC HU/CM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 11. No Go to the next step.
9	INSPECT BRAKE SWITCH CONNECTOR CONDITION - Disconnect the brake switch connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes Repair or replace the connector or terminals. Replace the brake switch, then go to Step 11. (See BRAKE PEDAL REMOVAL/ INSTALLATION.) No Go to the next step.
10	INSPECT BRAKE SWITCH SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY - Reconnect the negative battery cable. - Measure the voltage between DSC HU/CM terminal C (wiring harness-side) and body ground. - Is the voltage B+ ?	Yes Repair or replace the wiring harness for a possible short to power supply. Replace the brake switch, then go to the next step. (See BRAKE PEDAL REMOVAL/ INSTALLATION.) No Replace the brake switch, then go to the next step. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
11	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect the disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the DSC HU/CM memory using the M-MDS.	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)

	(See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Drive the vehicle at speed of 15 km/ h { 9.3 mph} or more. • Gradually slow down and stop the vehicle. • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?	No	Go to the next step.
12	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)] .)
		No	DTC troubleshooting completed.