

2012 - Mazda6 - Brakes


DTC C0020:01/ C0020:11/ C0020:13/ C0020:16/ C0020:1C/ C0020:71 [DYNAMIC STABILITY CONTROL (DSC)]

C0020:01	Pump motor, motor relay
C0020:11	
C0020:13	
C0020:16	
C0020:1C	
C0020:71	
DETECTION CONDITION	C0020:01 - Open circuit in motor relay monitor circuit is detected for 2 s, while the relay is off. C0020:11 - Motor relay monitor ON is detected for 4 s, while the relay is off. C0020:13 - Motor relay monitor off is detected for 0.12 s, while the relay is ON and motor fail-safe relay is off. - Motor relay monitor off is detected for 0.12 s, while the relay monitor is ON. C0020:16 - The voltage less than motor relay monitor off is detected for 4 s, while the relay is ON and motor fail-safe relay is off. C0020:1C - Motor relay monitor off is detected for 0.12 s, while the relay is ON. C0020:71 - Motor relay monitor voltage of 2 V or less is detected for a continuous 24 ms from when it has become 4.7 V or less after the motor check is initially



operated.

**POSSIBLE
CAUSE**

- Fuse malfunction
 - MAIN 125 A fuse
 - ABS MOTOR 60 A fuse
- Pump motor operation malfunction
- Connector or terminal malfunction
- Open circuit in wiring harness between DSC HU/CM terminal B and body ground
- Short to ground in wiring harness between battery positive terminal and DSC HU/CM terminal AH
- Open circuit in wiring harness between battery positive terminal and DSC HU/CM terminal AH
- DSC HU/CM malfunction
 - Motor relay malfunction



DSC HU/CM WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT FUSE - Switch the ignition to off. - Disconnect the negative battery cable. - Remove the following fuses: - MAIN 125 A fuse - ABS MOTOR 60 A fuse - Inspect the fuses.	Yes Replace the malfunctioning fuse, then go to Step 6. No Install the fuses, then go to the next step.

	Is there any malfunction?		
2	VERIFY PUMP MOTOR OPERATION - Reconnect the negative battery cable. - Switch the ignition to ON (engine off). - Access the active command mode for the pump motor using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Does the pump motor operate?	Yes	Go to the next step.
		No	Replace the DSC HU/CM, then go to Step 6. (See DSC HU/ CM REMOVAL/ INSTALLATION .)
3	INSPECT DSC HU/ CM CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the DSC HU/CM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
4	INSPECT ABS PUMP MOTOR GROUND CIRCUIT FOR OPEN CIRCUIT - Inspect for continuity between DSC HU/CM terminal B (wiring harness-side) and body ground. - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 6.
5	INSPECT ABS PUMP MOTOR POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between DSC HU/CM terminal AH (wiring harness-side) and body ground. - Is the voltage B+ ?	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to ground or open circuit, then go to the next step.

6	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect the disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the DSC HU/CM memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Drive the vehicle at speed of 6 km/ h { 4 mph} or more. • Gradually slow down and stop the vehicle. • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.) No Go to the next step.
7	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?		Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) No DTC troubleshooting completed.

2012 - Mazda6 - Brakes


DTC C0020:01/ C0020:11/ C0020:13/ C0020:16/ C0020:1C/ C0020:71 [DYNAMIC STABILITY CONTROL (DSC)]

C0020:01	Pump motor, motor relay
C0020:11	
C0020:13	
C0020:16	
C0020:1C	
C0020:71	
DETECTION CONDITION	C0020:01 - Open circuit in motor relay monitor circuit is detected for 2 s, while the relay is off. C0020:11 - Motor relay monitor ON is detected for 4 s, while the relay is off. C0020:13 - Motor relay monitor off is detected for 0.12 s, while the relay is ON and motor fail-safe relay is off. - Motor relay monitor off is detected for 0.12 s, while the relay monitor is ON. C0020:16 - The voltage less than motor relay monitor off is detected for 4 s, while the relay is ON and motor fail-safe relay is off. C0020:1C - Motor relay monitor off is detected for 0.12 s, while the relay is ON. C0020:71 - Motor relay monitor voltage of 2 V or less is detected for a continuous 24 ms from when it has become 4.7 V or less after the motor check is initially



operated.

**POSSIBLE
CAUSE**

- Fuse malfunction
 - MAIN 125 A fuse
 - ABS MOTOR 60 A fuse
- Pump motor operation malfunction
- Connector or terminal malfunction
- Open circuit in wiring harness between DSC HU/CM terminal B and body ground
- Short to ground in wiring harness between battery positive terminal and DSC HU/CM terminal AH
- Open circuit in wiring harness between battery positive terminal and DSC HU/CM terminal AH
- DSC HU/CM malfunction
 - Motor relay malfunction



DSC HU/CM WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT FUSE - Switch the ignition to off. - Disconnect the negative battery cable. - Remove the following fuses: - MAIN 125 A fuse - ABS MOTOR 60 A fuse - Inspect the fuses.	Yes Replace the malfunctioning fuse, then go to Step 6. No Install the fuses, then go to the next step.

	Is there any malfunction?		
2	VERIFY PUMP MOTOR OPERATION - Reconnect the negative battery cable. - Switch the ignition to ON (engine off). - Access the active command mode for the pump motor using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Does the pump motor operate?	Yes	Go to the next step.
		No	Replace the DSC HU/CM, then go to Step 6. (See DSC HU/ CM REMOVAL/ INSTALLATION .)
3	INSPECT DSC HU/ CM CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the DSC HU/CM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
4	INSPECT ABS PUMP MOTOR GROUND CIRCUIT FOR OPEN CIRCUIT - Inspect for continuity between DSC HU/CM terminal B (wiring harness-side) and body ground. - Is there continuity?	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 6.
5	INSPECT ABS PUMP MOTOR POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between DSC HU/CM terminal AH (wiring harness-side) and body ground. - Is the voltage B+ ?	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to ground or open circuit, then go to the next step.

6	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect the disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the DSC HU/CM memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Drive the vehicle at speed of 6 km/ h { 4 mph } or more. • Gradually slow down and stop the vehicle. • Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.) No Go to the next step.
7	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?		Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) No DTC troubleshooting completed.