




2012 - Mazda6 - Brakes

DTC C1137:64 [DYNAMIC STABILITY CONTROL (DSC)]



DTC 1137:64	Reverse signal (MTX)
DETECTI ON CONDI TION	• Detect the reverse signal for 10 s or more under the following condition: ▪ Vehicle speed: 60 km/ h { 37 mph} or more
POSSI BLE CAUSE	• BCM malfunction • Connector or terminal malfunction • Back-up light switch malfunction • Short to power supply in wiring harness between back-up light switch terminal B and BCM terminal 2H • DSC HU/CM malfunction



BCM
WIRING HARNESS-SIDE CONNECTOR



BACK-UP LIGHT SWITCH
WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	PERFORM BCM DTC INSPECTION - Perform the BCM DTC inspection using the M-MDS. (See DTC INSPECTION [BCM] .) - Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No Go to the next step.
2	INSPECT BACK-UP LIGHT SWITCH CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable.	Yes Repair or replace the connector or terminals, then go to Step 6.
		No Go to the next step.


	Disconnect the back-up light switch connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?		
3	INSPECT BACK-UP LIGHT SWITCH - Inspect the back-up light switch. (See BACK-UP LIGHT SWITCH INSPECTION.) - Is there any malfunction?	Yes Replace the back-up light switch, then go to Step 6. (See BACK-UP LIGHT SWITCH REMOVAL/ INSTALLATION [G66M-R].)	
		No Go to the next step.	
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 6.	
		No Go to the next step.	
5	INSPECT BACK-UP LIGHT SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY - Reconnect the negative battery cable. - Switch the ignition to ON (engine off). - Measure the voltage between back-up light switch terminal B (wiring harness-side) and body ground. - Is there any voltage?	Yes Repair or replace the wiring harness for a possible short to power supply, then go to the next step.	
		No Go to the next step.	
6	VERIFY DTC TROUBLESHOOTING COMPLETED - Reconnect the disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the DSC HU/CM memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Drive the vehicle at speed of 60 km/ h { 37 mph } or more. - Gradually slow down and stop the vehicle.	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)	
		No Go to the next step.	

	• Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		
7	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)] .)
		No	DTC troubleshooting completed.



2012 - Mazda6 - Brakes

DTC C1137:64 [DYNAMIC STABILITY CONTROL (DSC)]



DTC 1137:64	Reverse signal (MTX)
DETECTI ON CONDI TION	• Detect the reverse signal for 10 s or more under the following condition: ▪ Vehicle speed: 60 km/ h { 37 mph} or more
POSSI BLE CAUSE	• BCM malfunction • Connector or terminal malfunction • Back-up light switch malfunction • Short to power supply in wiring harness between back-up light switch terminal B and BCM terminal 2H • DSC HU/CM malfunction



BCM
WIRING HARNESS-SIDE CONNECTOR



BACK-UP LIGHT SWITCH
WIRING HARNESS-SIDE CONNECTOR



Diagnostic procedure

STEP	INSPECTION	ACTION
1	PERFORM BCM DTC INSPECTION - Perform the BCM DTC inspection using the M-MDS. (See DTC INSPECTION [BCM] .) - Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No Go to the next step.
2	INSPECT BACK-UP LIGHT SWITCH CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable.	Yes Repair or replace the connector or terminals, then go to Step 6.
		No Go to the next step.

	Disconnect the back-up light switch connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?		
3	INSPECT BACK-UP LIGHT SWITCH - Inspect the back-up light switch. (See BACK-UP LIGHT SWITCH INSPECTION.) - Is there any malfunction?	Yes	Replace the back-up light switch, then go to Step 6. (See BACK-UP LIGHT SWITCH REMOVAL/ INSTALLATION [G66M-R].)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect the connector and terminals (corrosion, damage, pin disconnection). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT BACK-UP LIGHT SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY - Reconnect the negative battery cable. - Switch the ignition to ON (engine off). - Measure the voltage between back-up light switch terminal B (wiring harness-side) and body ground. - Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
6	VERIFY DTC TROUBLESHOOTING COMPLETED - Reconnect the disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the DSC HU/CM memory using the M-MDS. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) - Drive the vehicle at speed of 60 km/ h { 37 mph} or more. - Gradually slow down and stop the vehicle.	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/ CM REMOVAL/ INSTALLATION.)
		No	Go to the next step.

	• Perform the DSC DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Is the same DTC present?		
7	VERIFY AFTER REPAIR PROCEDURE • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)] .)
		No	DTC troubleshooting completed.