

2012 - Mazda6 - Transmission/ Transaxle

DTC P0706:00 [AY6A-EL]

DTC P0706:00	TR switch circuit range/performance
DETECTION CONDITION	• Conditions: Battery voltage is normal • Circumstances: TR switch stuck detected • Time period: Determined after 2 consecutive times lasting 0.1 or more seconds Diagnostic support note: • The MIL illuminates if the TCM detects the above malfunction condition during the first drive cycle. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is available. • The DTC is stored in the TCM memory.
FAIL-SAFE FUNCTION	• Emergency mode 4 • Locks in D position, if the counter drive gear (output) speed signal (VSS) is 0 rpm
POSSIBLE CAUSE	• TR switch integrated in TCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA been recorded on the repair order?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA on the repair order, then go to the next step.

2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect all the disconnected connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Start the engine. ◦ Warm up the engine to normal operating temperature. ◦ Depress the brake pedal, and shift the selector lever from P to D for 5 s or more. • Is the same DTC present?	Yes	Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [AY6A-EL] .)
		No	Go to the next step.
4	VERIFY NO DTCs ARE PRESENT • Perform the "Reading DTCs Procedure". (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [AY6A-EL] .) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [AY6A-EL] .)
		No	DTC troubleshooting completed.

2012 - Mazda6 - Transmission/ Transaxle

DTC P0706:00 [AY6A-EL]

DTC P0706:00	TR switch circuit range/performance
DETECTION CONDITION	• Conditions: Battery voltage is normal • Circumstances: TR switch stuck detected • Time period: Determined after 2 consecutive times lasting 0.1 or more seconds Diagnostic support note: • The MIL illuminates if the TCM detects the above malfunction condition during the first drive cycle. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is available. • The DTC is stored in the TCM memory.
FAIL-SAFE FUNCTION	• Emergency mode 4 • Locks in D position, if the counter drive gear (output) speed signal (VSS) is 0 rpm
POSSIBLE CAUSE	• TR switch integrated in TCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA been recorded on the repair order?	YesGo to the next step.
		NoRecord the FREEZE FRAME DATA on the repair order, then go to the next step.

2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY DTC TROUBLESHOOTING COMPLETED • Make sure to reconnect all the disconnected connectors. • Clear the DTC using the M-MDS. • Perform the following procedure to ensure that the DTC has been resolved: ◦ Start the engine. ◦ Warm up the engine to normal operating temperature. ◦ Depress the brake pedal, and shift the selector lever from P to D for 5 s or more. • Is the same DTC present?	Yes	Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [AY6A-EL] .)
		No	Go to the next step.
4	VERIFY NO DTCs ARE PRESENT • Perform the "Reading DTCs Procedure". (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [AY6A-EL] .) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [AY6A-EL] .)
		No	DTC troubleshooting completed.