


2012 - Mazda6 - Transmission/ Transaxle

DTC P2764:00 [AY6A-EL]

DTC P2764:00	TCC control solenoid circuit low
DETECTION CONDITION	• Conditions: TCM communication normal • Circumstances: TCC control solenoid system disconnection or short circuit to GND detected • Time period: Determined after 5 consecutive times lasting 0.1 or more seconds Diagnostic support note: • The MIL illuminates if the TCM detects the above malfunction condition during the first drive cycle. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is available. • The DTC is stored in the TCM memory.
FAIL-SAFE FUNCTION	• Inhibits learning control • Inhibits TCC control • Inhibits slip control • Inhibits adaptive shift control
POSSIBLE CAUSE	• Coupler component connector or terminal malfunction • Short to GND in wiring harness between TCC control solenoid terminal B and TCM terminal B9 • Short to GND in wiring harness between TCC control solenoid terminal A and TCM terminal B4 • Open circuit between TCC control solenoid terminal B and TCM terminal B9 • Open circuit between TCC control solenoid terminal A and TCM terminal B4 • TCC control solenoid connector or terminal malfunction

- Solenoid valve malfunction
 - TCC control solenoid
- TCM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION

1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED Has the FREEZE FRAME DATA been recorded on the repair order?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT COUPLER COMPONENT CONNECTOR FOR POOR CONNECTION - Switch the ignition OFF (LOCK). - Remove the TCM. (See TCM REMOVAL/ INSTALLATION [AY6A-EL].) - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the terminal, then go to Step 8.
		No Go to the next step.
4	INSPECT TCC CONTROL SOLENOID CIRCUIT FOR SHORT TO GND - Switch the ignition OFF (LOCK). - Inspect for continuity between the following circuits: - Coupler component terminal B9 (wiring harness-side) and body GND - Coupler component terminal B4 (wiring harness-side) and body GND - Is there continuity?	Yes Repair or replace the wiring harness for a possible short to GND, then go to Step 8.
		No Go to the next step.
5	INSPECT TCC CONTROL SOLENOID CONNECTOR FOR POOR CONNECTION - Switch the ignition OFF (LOCK). - Disconnect the TCC control solenoid connector. - Inspect for poor connection (such as	Yes Repair or replace the terminal, then go to Step 8.
		No Go to the next step.

	damaged/pulled-out pins, corrosion). Is there any malfunction?		
6	INSPECT TCC CONTROL SOLENOID - Inspect the TCC control solenoid. (See TORQUE CONVERTER CLUTCH (TCC) CONTROL SOLENOID INSPECTION [AY6A-EL].) - Is there any malfunction?	Yes Replace the control valve body, then go to Step 8. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [AY6A-EL].)	
		No Go to the next step.	
7	INSPECT TCC CONTROL SOLENOID CIRCUIT FOR OPEN CIRCUIT - Switch the ignition OFF (LOCK). - Inspect for continuity between the following circuits: - TCC control solenoid terminal B (wiring harness-side) and coupler component terminal B9 (wiring harness-side) - TCC control solenoid terminal A (wiring harness-side) and coupler component terminal B4 (wiring harness-side) - Is there continuity?	Yes Go to the next step.	
		No Repair or replace the wiring harness for a possible open circuit, then go to the next step.	
8	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect all the disconnected connectors. - Clear the DTC using the M-MDS. - Perform the following procedure to ensure that the DTC has been resolved: - Start the engine. - Warm up the engine and transaxle. - Drive the vehicle in D position and make sure that the gears shift smoothly from 1GR to 6GR and TCC is operated. - Is the same DTC present?	Yes Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [AY6A-EL].)	
		No Go to the next step.	
9	VERIFY NO DTCs ARE PRESENT Perform the "Reading DTCs Procedure".	Yes Go to the applicable DTC inspection.	


	(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [AY6A-EL] .)		(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [AY6A-EL] .)
	• Are any DTCs present?		No DTC troubleshooting completed.

2012 - Mazda6 - Transmission/ Transaxle

DTC P2764:00 [AY6A-EL]

DTC P2764:00	TCC control solenoid circuit low
DETECTION CONDITION	• Conditions: TCM communication normal • Circumstances: TCC control solenoid system disconnection or short circuit to GND detected • Time period: Determined after 5 consecutive times lasting 0.1 or more seconds Diagnostic support note: • The MIL illuminates if the TCM detects the above malfunction condition during the first drive cycle. • The AT warning light illuminates. • PENDING CODE is not available. • FREEZE FRAME DATA is available. • The DTC is stored in the TCM memory.
FAIL-SAFE FUNCTION	• Inhibits learning control • Inhibits TCC control • Inhibits slip control • Inhibits adaptive shift control
POSSIBLE CAUSE	• Coupler component connector or terminal malfunction • Short to GND in wiring harness between TCC control solenoid terminal B and TCM terminal B9 • Short to GND in wiring harness between TCC control solenoid terminal A and TCM terminal B4 • Open circuit between TCC control solenoid terminal B and TCM terminal B9 • Open circuit between TCC control solenoid terminal A and TCM terminal B4 • TCC control solenoid connector or terminal malfunction

- Solenoid valve malfunction
 - TCC control solenoid
- TCM malfunction



Diagnostic procedure

STEP	INSPECTION	ACTION

1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED Has the FREEZE FRAME DATA been recorded on the repair order?	Yes Go to the next step. No Record the FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. If the vehicle is not repaired, go to the next step. No Go to the next step.
3	INSPECT COUPLER COMPONENT CONNECTOR FOR POOR CONNECTION - Switch the ignition OFF (LOCK). - Remove the TCM. (See TCM REMOVAL/ INSTALLATION [AY6A-EL].) - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the terminal, then go to Step 8. No Go to the next step.
4	INSPECT TCC CONTROL SOLENOID CIRCUIT FOR SHORT TO GND - Switch the ignition OFF (LOCK). - Inspect for continuity between the following circuits: - Coupler component terminal B9 (wiring harness-side) and body GND - Coupler component terminal B4 (wiring harness-side) and body GND - Is there continuity?	Yes Repair or replace the wiring harness for a possible short to GND, then go to Step 8. No Go to the next step.
5	INSPECT TCC CONTROL SOLENOID CONNECTOR FOR POOR CONNECTION - Switch the ignition OFF (LOCK). - Disconnect the TCC control solenoid connector. - Inspect for poor connection (such as	Yes Repair or replace the terminal, then go to Step 8. No Go to the next step.

	damaged/pulled-out pins, corrosion). Is there any malfunction?		
6	INSPECT TCC CONTROL SOLENOID - Inspect the TCC control solenoid. (See TORQUE CONVERTER CLUTCH (TCC) CONTROL SOLENOID INSPECTION [AY6A-EL].) - Is there any malfunction?	Yes Replace the control valve body, then go to Step 8. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [AY6A-EL].)	
		No Go to the next step.	
7	INSPECT TCC CONTROL SOLENOID CIRCUIT FOR OPEN CIRCUIT - Switch the ignition OFF (LOCK). - Inspect for continuity between the following circuits: - TCC control solenoid terminal B (wiring harness-side) and coupler component terminal B9 (wiring harness-side) - TCC control solenoid terminal A (wiring harness-side) and coupler component terminal B4 (wiring harness-side) - Is there continuity?	Yes Go to the next step.	
		No Repair or replace the wiring harness for a possible open circuit, then go to the next step.	
8	VERIFY DTC TROUBLESHOOTING COMPLETED - Make sure to reconnect all the disconnected connectors. - Clear the DTC using the M-MDS. - Perform the following procedure to ensure that the DTC has been resolved: - Start the engine. - Warm up the engine and transaxle. - Drive the vehicle in D position and make sure that the gears shift smoothly from 1GR to 6GR and TCC is operated. - Is the same DTC present?	Yes Replace the TCM, then go to the next step. (See TCM REMOVAL/ INSTALLATION [AY6A-EL].)	
		No Go to the next step.	
9	VERIFY NO DTCs ARE PRESENT Perform the "Reading DTCs Procedure".	Yes Go to the applicable DTC inspection.	

	(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [AY6A-EL] .)		(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [AY6A-EL] .)
	• Are any DTCs present?		No DTC troubleshooting completed.