


2012 - Mazda6 - Body and Accessories


DTC B1048:11 [BCM]

DESCRIPTION	Brake fluid level sensor circuit malfunction
DETECTION CONDITION	• Short to ground in brake fluid level sensor circuit with the brake fluid amount on the upper side of the minimum.
POSSIBLE CAUSE	• Brake fluid level sensor connector or terminals malfunction • Brake fluid level sensor malfunction • BCM connector or terminals malfunction • Short to ground in wiring harness between brake fluid level sensor terminal A and BCM terminal 1Q • BCM malfunction



BCM




BRAKE FLUID LEVEL SENSOR



BCM WIRING HARNESS-SIDE CONNECTOR



BRAKE FLUID LEVEL SENSOR WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the brake fluid amount on the upper side of the minimum. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step.
		No Go to Step 7.
2	INSPECT BRAKE FLUID LEVEL SENSOR CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the brake fluid level sensor	Yes Repair or replace the connector or terminals, then go to Step 6.
		No Go to the next step.

	connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?		
3	INSPECT BRAKE FLUID LEVEL SENSOR - Inspect the brake fluid level sensor. (See BRAKE FLUID LEVEL SENSOR INSPECTION.) - Is there any malfunction?	Yes	Replace the brake fluid level sensor, then go to Step 6. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT BRAKE FLUID LEVEL SENSOR CIRCUIT FOR SHORT TO GROUND - Brake fluid level sensor and BCM connectors are disconnected. - Inspect for continuity between brake fluid level sensor terminal A (wiring harness-side) and body ground. - Is there continuity?	Yes	Repair or replace the wiring harness for a possible short to ground, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the brake fluid amount on the upper side of the minimum. (See DTC INSPECTION [BCM].)	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.


	Is the same DTC present?		
7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.

2012 - Mazda6 - Body and Accessories


DTC B1048:11 [BCM]

DESCRIPTION	Brake fluid level sensor circuit malfunction
DETECTION CONDITION	• Short to ground in brake fluid level sensor circuit with the brake fluid amount on the upper side of the minimum.
POSSIBLE CAUSE	• Brake fluid level sensor connector or terminals malfunction • Brake fluid level sensor malfunction • BCM connector or terminals malfunction • Short to ground in wiring harness between brake fluid level sensor terminal A and BCM terminal 1Q • BCM malfunction



BCM




BRAKE FLUID LEVEL SENSOR



BCM WIRING HARNESS-SIDE CONNECTOR



BRAKE FLUID LEVEL SENSOR WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the brake fluid amount on the upper side of the minimum. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step.
		No Go to Step 7.
2	INSPECT BRAKE FLUID LEVEL SENSOR CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the brake fluid level sensor	Yes Repair or replace the connector or terminals, then go to Step 6.
		No Go to the next step.

	connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?		
3	INSPECT BRAKE FLUID LEVEL SENSOR - Inspect the brake fluid level sensor. (See BRAKE FLUID LEVEL SENSOR INSPECTION.) - Is there any malfunction?	Yes	Replace the brake fluid level sensor, then go to Step 6. (See BRAKE PEDAL REMOVAL/ INSTALLATION.)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT BRAKE FLUID LEVEL SENSOR CIRCUIT FOR SHORT TO GROUND - Brake fluid level sensor and BCM connectors are disconnected. - Inspect for continuity between brake fluid level sensor terminal A (wiring harness-side) and body ground. - Is there continuity?	Yes	Repair or replace the wiring harness for a possible short to ground, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the brake fluid amount on the upper side of the minimum. (See DTC INSPECTION [BCM].)	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.

	Is the same DTC present?		
7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.