


2012 - Mazda6 - Body and Accessories

DTC C1137:12 [BCM]

MZR 2.5/ ATX



DESCRIPTION	Transaxle range switch circuit malfunction
DETECTION CONDITION	• Short to power supply in transaxle range switch circuit with the selector lever in P or N position (transaxle range switch off).
POSSIBLE CAUSE	• Transaxle range switch connector or terminals malfunction • Transaxle range switch malfunction • BCM connector or terminals malfunction • Short to power supply in wiring harness between transaxle range switch terminal D and BCM terminal 2H • Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A • BCM malfunction



BCM WIRING HARNESS-SIDE CONNECTOR

TRANSAXLE RANGE SWITCH WIRING HARNESS-SIDE CONNECTOR

BACK-UP LIGHT (LH/RH) WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure


Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position (transaxle range switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 7.
2	INSPECT TRANSAXLE RANGE SWITCH CONNECTOR CONDITION Switch the ignition to off.	Yes Repair or replace the connector or terminals, then go to Step 6.

	• Disconnect the negative battery cable. • Disconnect the transaxle range switch connector. • Inspect for poor connection (damaged/pulled-out pins, corrosion). • Is there any malfunction?	No	Go to the next step.
3	INSPECT TRANSAXLE RANGE SWITCH • Inspect the transaxle range switch. (See TRANSAXLE RANGE (TR) SWITCH INSPECTION [FS5A-EL] .) • Is there any malfunction?	Yes	Replace the transaxle range switch, then go to Step 6. (See TRANSAXLE RANGE (TR) SWITCH REMOVAL/ INSTALLATION [FS5A-EL] .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION • Disconnect the BCM connector. • Inspect for poor connection (damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT TRANSAXLE RANGE SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY • Transaxle range switch and BCM connectors are disconnected. • Reconnect the negative battery cable. • Switch the ignition to ON. • Measure the voltage between the following terminals and body ground: ▪ Transaxle range switch terminal D (wiring harness-side) ▪ Back-up light (LH/RH) terminal A (wiring harness-side) • Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED • Make sure to reconnect all disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM] .) • Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position (transaxle range switch off). (See DTC INSPECTION [BCM] .) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.

7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.

MZR 2.5/ MTX

DESCRIPTION	Back-up light switch circuit malfunction
DETECTION CONDITION	Short to power supply in back-up light switch circuit with the shift lever in NEUTRAL (back-up light switch off).
POSSIBLE CAUSE	- Back-up light switch connector or terminals malfunction - Back-up light switch malfunction - BCM connector or terminals malfunction - Short to power supply in wiring harness between back-up light switch terminal B and BCM terminal 2H - Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A - BCM malfunction



Diagnostic Procedure


Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the shift lever in NEUTRAL (back-up light switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 7.
2	INSPECT BACK-UP LIGHT SWITCH CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the back-up light switch connector.	Yes Repair or replace the connector or terminals, then go to Step 6. No Go to the next step.

	- Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?		
3	INSPECT BACK-UP LIGHT SWITCH - Inspect the back-up light switch. (See BACK-UP LIGHT SWITCH INSPECTION.) - Is there any malfunction?	Yes	Replace the back-up light switch, then go to Step 6. (See BACK-UP LIGHT SWITCH REMOVAL/ INSTALLATION [G66M-R] .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT BACK-UP LIGHT SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY - Back-up light switch and BCM connectors are disconnected. - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between the following terminals and body ground: - Back-up light switch terminal B (wiring harness-side) - Back-up light (LH/RH) terminal A (wiring harness-side) - Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the shift lever in NEUTRAL (back-up light switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
7	VERIFY THAT NO OTHER DTCs ARE PRESENT	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)

	• Are any DTCs present?		
		No DTC troubleshooting completed.	

MZI 3.7 V6

DESCRIPTION	Back-up light relay circuit malfunction
DETECTION CONDITION	• Short to power supply in back-up light relay circuit with the selector lever in P or N position.
POSSIBLE CAUSE	• Back-up light relay malfunction • BCM connector or terminals malfunction • Short to power supply in wiring harness between back-up light relay terminal C and BCM terminal 2H • Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A • BCM malfunction



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 6.
2	INSPECT BACK-UP LIGHT RELAY - Switch the ignition to off. - Disconnect the negative battery cable.	Yes Replace the back-up light relay, then go to Step 5. No Go to the next step.

	- Remove the back-up light relay. - Inspect the back-up light relay. (See RELAY INSPECTION.) - Is there any malfunction?		
3	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 5.
		No	Go to the next step.
4	INSPECT BACK-UP LIGHT RELAY CIRCUIT FOR SHORT TO POWER SUPPLY - Back-up light relay is removed. - BCM connector is disconnected. - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between the following terminals and body ground: - Back-up light relay terminal C (wiring harness-side) - Back-up light (LH/RH) terminal A (wiring harness-side) - Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
5	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
6	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)

	No DTC troubleshooting completed.
--	-----------------------------------

[< Previous](#) [Next >](#)

[Back to Top](#)


© 2012 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Body and Accessories

DTC C1137:12 [BCM]

MZR 2.5/ ATX




DESCRIPTION	Transaxle range switch circuit malfunction
DETECTION CONDITION	• Short to power supply in transaxle range switch circuit with the selector lever in P or N position (transaxle range switch off).
POSSIBLE CAUSE	• Transaxle range switch connector or terminals malfunction • Transaxle range switch malfunction • BCM connector or terminals malfunction • Short to power supply in wiring harness between transaxle range switch terminal D and BCM terminal 2H • Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A • BCM malfunction



BCM WIRING HARNESS-SIDE CONNECTOR

TRANSAXLE RANGE SWITCH WIRING HARNESS-SIDE CONNECTOR

BACK-UP LIGHT (LH/RH) WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure


Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position (transaxle range switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 7.
2	INSPECT TRANSAXLE RANGE SWITCH CONNECTOR CONDITION Switch the ignition to off.	Yes Repair or replace the connector or terminals, then go to Step 6.

	• Disconnect the negative battery cable. • Disconnect the transaxle range switch connector. • Inspect for poor connection (damaged/pulled-out pins, corrosion). • Is there any malfunction?	No	Go to the next step.
3	INSPECT TRANSAXLE RANGE SWITCH • Inspect the transaxle range switch. (See TRANSAXLE RANGE (TR) SWITCH INSPECTION [FS5A-EL] .) • Is there any malfunction?	Yes	Replace the transaxle range switch, then go to Step 6. (See TRANSAXLE RANGE (TR) SWITCH REMOVAL/ INSTALLATION [FS5A-EL] .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION • Disconnect the BCM connector. • Inspect for poor connection (damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT TRANSAXLE RANGE SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY • Transaxle range switch and BCM connectors are disconnected. • Reconnect the negative battery cable. • Switch the ignition to ON. • Measure the voltage between the following terminals and body ground: ▪ Transaxle range switch terminal D (wiring harness-side) ▪ Back-up light (LH/RH) terminal A (wiring harness-side) • Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED • Make sure to reconnect all disconnected connectors. • Reconnect the negative battery cable. • Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM] .) • Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position (transaxle range switch off). (See DTC INSPECTION [BCM] .) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No	Go to the next step.

7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.

MZR 2.5/ MTX

DESCRIPTION	Back-up light switch circuit malfunction
DETECTION CONDITION	Short to power supply in back-up light switch circuit with the shift lever in NEUTRAL (back-up light switch off).
POSSIBLE CAUSE	- Back-up light switch connector or terminals malfunction - Back-up light switch malfunction - BCM connector or terminals malfunction - Short to power supply in wiring harness between back-up light switch terminal B and BCM terminal 2H - Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A - BCM malfunction



Diagnostic Procedure


Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the shift lever in NEUTRAL (back-up light switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 7.
2	INSPECT BACK-UP LIGHT SWITCH CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the back-up light switch connector.	Yes Repair or replace the connector or terminals, then go to Step 6. No Go to the next step.

	- Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?		
3	INSPECT BACK-UP LIGHT SWITCH - Inspect the back-up light switch. (See BACK-UP LIGHT SWITCH INSPECTION.) - Is there any malfunction?	Yes	Replace the back-up light switch, then go to Step 6. (See BACK-UP LIGHT SWITCH REMOVAL/ INSTALLATION [G66M-R] .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT BACK-UP LIGHT SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY - Back-up light switch and BCM connectors are disconnected. - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between the following terminals and body ground: - Back-up light switch terminal B (wiring harness-side) - Back-up light (LH/RH) terminal A (wiring harness-side) - Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the shift lever in NEUTRAL (back-up light switch off). (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
7	VERIFY THAT NO OTHER DTCs ARE PRESENT	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)

	• Are any DTCs present?		
			No DTC troubleshooting completed.

MZI 3.7 V6

DESCRIPTION	Back-up light relay circuit malfunction
DETECTION CONDITION	• Short to power supply in back-up light relay circuit with the selector lever in P or N position.
POSSIBLE CAUSE	• Back-up light relay malfunction • BCM connector or terminals malfunction • Short to power supply in wiring harness between back-up light relay terminal C and BCM terminal 2H • Short to power supply in wiring harness between back-up light (LH/RH) terminal A and BCM terminal 7A • BCM malfunction



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 6.
2	INSPECT BACK-UP LIGHT RELAY - Switch the ignition to off. - Disconnect the negative battery cable.	Yes Replace the back-up light relay, then go to Step 5. No Go to the next step.

	- Remove the back-up light relay. - Inspect the back-up light relay. (See RELAY INSPECTION.) - Is there any malfunction?		
3	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 5.
		No	Go to the next step.
4	INSPECT BACK-UP LIGHT RELAY CIRCUIT FOR SHORT TO POWER SUPPLY - Back-up light relay is removed. - BCM connector is disconnected. - Reconnect the negative battery cable. - Switch the ignition to ON. - Measure the voltage between the following terminals and body ground: - Back-up light relay terminal C (wiring harness-side) - Back-up light (LH/RH) terminal A (wiring harness-side) - Is there any voltage?	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Go to the next step.
5	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the selector lever in P or N position. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
6	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)

	No DTC troubleshooting completed.
--	-----------------------------------

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.