


2012 - Mazda6 - Body and Accessories

DTC B126A:11 [BCM]

Vehicles With Advanced Keyless Entry And Push Button Start System

DESCRIPTION	Front door lock-link switch (driver-side) circuit malfunction
DETECTION CONDITION	• Short to ground detected in front door lock-link switch (driver-side) lock-side circuit with the front door lock-link switch (driver-side) unlocked.
POSSIBLE CAUSE	• Front door latch and lock actuator (driver-side) connector or terminals malfunction • Front door lock-link switch (driver-side) malfunction • Keyless control module connector or terminals malfunction • BCM connector or terminals malfunction • Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and BCM terminal 8G • Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and keyless control module terminal 3P • Keyless control module malfunction • BCM malfunction




Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 9.
2	INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (DRIVER-SIDE) CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the front door latch and lock actuator (driver-side) connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8. No Go to the next step.
3	INSPECT FRONT DOOR LOCK-LINK SWITCH	Yes Replace the front door latch and lock actuator (driver-side),

	(DRIVER-SIDE) - Inspect the front door lock-link switch (driver-side). (See DOOR LOCK-LINK SWITCH INSPECTION.) - Is there any malfunction?	then go to Step 8. (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/ INSTALLATION.)
		No Go to the next step.
4	INSPECT KEYLESS CONTROL MODULE CONNECTOR CONDITION - Disconnect the keyless control module connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8.
		No Go to the next step.
5	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8.
		No Go to the next step.
6	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) CIRCUIT FOR SHORT TO GROUND - Front door latch and lock actuator (driver-side), keyless control module and BCM connectors are disconnected. - Inspect for continuity between front door latch and lock actuator (driver-side) terminal D (wiring harness-side) and body ground. - Is there continuity?	Yes Repair or replace the wiring harness for a possible short to ground, then go to Step 8.
		No Go to the next step.
7	INSPECT KEYLESS CONTROL MODULE - Front door latch and lock actuator (driver-side), keyless control module and BCM connectors are disconnected. - Reconnect all disconnected connectors. - Reconnect the negative battery cable. - Measure the voltage between keyless control module terminal 3P (wiring harness-side) and body ground. - Is the voltage normal? (See KEYLESS CONTROL MODULE INSPECTION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM].)	Yes Go to the next step.
		No Replace the keyless control module, then go to the next step. (See KEYLESS CONTROL MODULE REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM].)
8	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.)
		No Go to the next step.
9	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [BCM].)

Vehicles Without Advanced Keyless Entry And Push Button Start System

DESCRIPTION	Front door lock-link switch (driver-side) circuit malfunction
DETECTION CONDITION	Short to ground detected in front door lock-link switch (driver-side) lock-side circuit with the front door lock-link switch (driver-side) unlocked.
POSSIBLE CAUSE	- Front door latch and lock actuator (driver-side) connector or terminals malfunction - Front door lock-link switch (driver-side) malfunction - BCM connector or terminals malfunction - Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and BCM terminal 8G - BCM malfunction



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM] .) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM] .)	Yes Go to the next step. No Go to Step 7.


	Is the same DTC present?		
2	INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (DRIVER-SIDE) CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the front door latch and lock actuator (driver-side) connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
3	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) - Inspect the front door lock-link switch (driver-side). (See DOOR LOCK-LINK SWITCH INSPECTION.) - Is there any malfunction?	Yes	Replace the front door latch and lock actuator (driver-side), then go to Step 6. (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/ INSTALLATION .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) CIRCUIT FOR SHORT TO GROUND - Front door latch and lock actuator (driver-side) and BCM connectors are disconnected. - Inspect for continuity between front door latch and lock actuator (driver-side) terminal D (wiring harness-side) and body ground. - Is there continuity?	Yes	Repair or replace the wiring harness for a possible short to ground, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.

2012 - Mazda6 - Body and Accessories

DTC B126A:11 [BCM]

Vehicles With Advanced Keyless Entry And Push Button Start System

DESCRIPTION	Front door lock-link switch (driver-side) circuit malfunction
DETECTION CONDITION	• Short to ground detected in front door lock-link switch (driver-side) lock-side circuit with the front door lock-link switch (driver-side) unlocked.
POSSIBLE CAUSE	• Front door latch and lock actuator (driver-side) connector or terminals malfunction • Front door lock-link switch (driver-side) malfunction • Keyless control module connector or terminals malfunction • BCM connector or terminals malfunction • Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and BCM terminal 8G • Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and keyless control module terminal 3P • Keyless control module malfunction • BCM malfunction




Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Go to the next step. No Go to Step 9.
2	INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (DRIVER-SIDE) CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the front door latch and lock actuator (driver-side) connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8. No Go to the next step.
3	INSPECT FRONT DOOR LOCK-LINK SWITCH	Yes Replace the front door latch and lock actuator (driver-side),

	(DRIVER-SIDE) - Inspect the front door lock-link switch (driver-side). (See DOOR LOCK-LINK SWITCH INSPECTION.) - Is there any malfunction?	then go to Step 8. (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/ INSTALLATION.)
		No Go to the next step.
4	INSPECT KEYLESS CONTROL MODULE CONNECTOR CONDITION - Disconnect the keyless control module connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8. No Go to the next step.
5	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes Repair or replace the connector or terminals, then go to Step 8. No Go to the next step.
6	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) CIRCUIT FOR SHORT TO GROUND - Front door latch and lock actuator (driver-side), keyless control module and BCM connectors are disconnected. - Inspect for continuity between front door latch and lock actuator (driver-side) terminal D (wiring harness-side) and body ground. - Is there continuity?	Yes Repair or replace the wiring harness for a possible short to ground, then go to Step 8. No Go to the next step.
7	INSPECT KEYLESS CONTROL MODULE - Front door latch and lock actuator (driver-side), keyless control module and BCM connectors are disconnected. - Reconnect all disconnected connectors. - Reconnect the negative battery cable. - Measure the voltage between keyless control module terminal 3P (wiring harness-side) and body ground. - Is the voltage normal? (See KEYLESS CONTROL MODULE INSPECTION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM].)	Yes Go to the next step. No Replace the keyless control module, then go to the next step. (See KEYLESS CONTROL MODULE REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM].)
8	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION.) No Go to the next step.
9	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [BCM].)

Vehicles Without Advanced Keyless Entry And Push Button Start System

DESCRIPTION	Front door lock-link switch (driver-side) circuit malfunction
DETECTION CONDITION	Short to ground detected in front door lock-link switch (driver-side) lock-side circuit with the front door lock-link switch (driver-side) unlocked.
POSSIBLE CAUSE	- Front door latch and lock actuator (driver-side) connector or terminals malfunction - Front door lock-link switch (driver-side) malfunction - BCM connector or terminals malfunction - Short to ground in wiring harness between front door latch and lock actuator (driver-side) terminal D and BCM terminal 8G - BCM malfunction



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM] .) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM] .)	YesGo to the next step. NoGo to Step 7.

	Is the same DTC present?		
2	INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (DRIVER-SIDE) CONNECTOR CONDITION - Switch the ignition to off. - Disconnect the negative battery cable. - Disconnect the front door latch and lock actuator (driver-side) connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
3	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) - Inspect the front door lock-link switch (driver-side). (See DOOR LOCK-LINK SWITCH INSPECTION.) - Is there any malfunction?	Yes	Replace the front door latch and lock actuator (driver-side), then go to Step 6. (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/ INSTALLATION .)
		No	Go to the next step.
4	INSPECT BCM CONNECTOR CONDITION - Disconnect the BCM connector. - Inspect for poor connection (damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector or terminals, then go to Step 6.
		No	Go to the next step.
5	INSPECT FRONT DOOR LOCK-LINK SWITCH (DRIVER-SIDE) CIRCUIT FOR SHORT TO GROUND - Front door latch and lock actuator (driver-side) and BCM connectors are disconnected. - Inspect for continuity between front door latch and lock actuator (driver-side) terminal D (wiring harness-side) and body ground. - Is there continuity?	Yes	Repair or replace the wiring harness for a possible short to ground, then go to the next step.
		No	Go to the next step.
6	VERIFY TROUBLESHOOTING COMPLETED - Make sure to reconnect all disconnected connectors. - Reconnect the negative battery cable. - Clear the DTC from the BCM memory using the M-MDS. (See CLEARING DTC [BCM].) - Perform the BCM DTC inspection using the M-MDS with the front door lock-link switch (driver-side) unlocked. (See DTC INSPECTION [BCM].) - Is the same DTC present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the BCM, then go to the next step. (See BODY CONTROL MODULE (BCM) REMOVAL/ INSTALLATION .)
		No	Go to the next step.
7	VERIFY THAT NO OTHER DTCs ARE PRESENT Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [BCM] .)
		No	DTC troubleshooting completed.