

2012 - Mazda6 - Body and Accessories

REAR DRAIN HOSE INSTALLATION

CAUTION:

- If the rear drain hose is pinched or bent anywhere, the water in the hose may not discharge and enter the inside of the vehicle. During and after installation of the trims and the headliner, always make sure there is no interference with the rear drain hose. Fix any problem if found.

1. Apply soapy water to the rear drain hose inserting area.
2. Insert one end (the wider side) of the rear drain hose into the sunroof frame.
3. Install the rear drain hose to the clips parallel to the pillar and free of slack.
4. Insert the rear drain hose joint into the rear pillar inner hole.
5. Install the trunk side trim. (See [TRUNK SIDE TRIM REMOVAL/ INSTALLATION.](#))
6. Install the trunk end trim (See [TRUNK END TRIM REMOVAL/ INSTALLATION.](#))
7. Install the headliner. (See [HEADLINER REMOVAL/ INSTALLATION.](#))
8. Install the map light. (See [MAP LIGHT REMOVAL/ INSTALLATION.](#))
9. Install the assist handle. (See [ASSIST HANDLE REMOVAL/ INSTALLATION.](#))
10. Install the sunvisors. (See [SUNVISOR REMOVAL/ INSTALLATION.](#))
11. Connect the rain sensor connector. (vehicles with rain sensor)
12. Connect the dimming mirror connector. (vehicles with dimming mirror)
13. Install the following parts:
 - a. C-pillar trims (See [C-PILLAR TRIM REMOVAL/ INSTALLATION.](#))
 - b. Rear side seat back (See [REAR SIDE SEAT BACK REMOVAL/ INSTALLATION.](#))
 - c. Rear seat cushion (See [REAR SEAT CUSHION REMOVAL/ INSTALLATION.](#))
 - d. B-pillar upper trims (See [B-PILLAR UPPER TRIM REMOVAL/ INSTALLATION.](#))
 - e. B-pillar lower trims (See [B-PILLAR LOWER TRIM REMOVAL/ INSTALLATION.](#))
 - f. Rear scuff plate inner (See [REAR SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - g. Front scuff plate (See [FRONT SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - h. Upper anchor of the front seat belt (See [FRONT SEAT BELT REMOVAL/ INSTALLATION.](#))
 - i. A-pillar trims (See [A-PILLAR TRIM REMOVAL/ INSTALLATION.](#))
 - j. Sunroof seaming welt

14. Install the seaming welt.

15. Connect the negative battery cable.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Body and Accessories

REAR DRAIN HOSE INSTALLATION

CAUTION:

- If the rear drain hose is pinched or bent anywhere, the water in the hose may not discharge and enter the inside of the vehicle. During and after installation of the trims and the headliner, always make sure there is no interference with the rear drain hose. Fix any problem if found.

1. Apply soapy water to the rear drain hose inserting area.
2. Insert one end (the wider side) of the rear drain hose into the sunroof frame.
3. Install the rear drain hose to the clips parallel to the pillar and free of slack.
4. Insert the rear drain hose joint into the rear pillar inner hole.
5. Install the trunk side trim. (See [TRUNK SIDE TRIM REMOVAL/ INSTALLATION.](#))
6. Install the trunk end trim (See [TRUNK END TRIM REMOVAL/ INSTALLATION.](#))
7. Install the headliner. (See [HEADLINER REMOVAL/ INSTALLATION.](#))
8. Install the map light. (See [MAP LIGHT REMOVAL/ INSTALLATION.](#))
9. Install the assist handle. (See [ASSIST HANDLE REMOVAL/ INSTALLATION.](#))
10. Install the sunvisors. (See [SUNVISOR REMOVAL/ INSTALLATION.](#))
11. Connect the rain sensor connector. (vehicles with rain sensor)
12. Connect the dimming mirror connector. (vehicles with dimming mirror)
13. Install the following parts:
 - a. C-pillar trims (See [C-PILLAR TRIM REMOVAL/ INSTALLATION.](#))
 - b. Rear side seat back (See [REAR SIDE SEAT BACK REMOVAL/ INSTALLATION.](#))
 - c. Rear seat cushion (See [REAR SEAT CUSHION REMOVAL/ INSTALLATION.](#))
 - d. B-pillar upper trims (See [B-PILLAR UPPER TRIM REMOVAL/ INSTALLATION.](#))
 - e. B-pillar lower trims (See [B-PILLAR LOWER TRIM REMOVAL/ INSTALLATION.](#))
 - f. Rear scuff plate inner (See [REAR SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - g. Front scuff plate (See [FRONT SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - h. Upper anchor of the front seat belt (See [FRONT SEAT BELT REMOVAL/ INSTALLATION.](#))
 - i. A-pillar trims (See [A-PILLAR TRIM REMOVAL/ INSTALLATION.](#))
 - j. Sunroof seaming welt

14. Install the seaming welt.

15. Connect the negative battery cable.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.