





[< Previous](#)

2012 - Mazda6 - Brakes

BRAKES SST

49 0221 600C Disc brake expand tool		49 F043 002 Wrench		49 U043 004A Oil pressure gauge (Part of 49 U043 0A0A)	
49 U043 005 Joint (Part of 49 U043 0A0A)		49 U043 006 Hose (Part of 49 U043 0A0A)		—	





[< Previous](#)

[Back to Top](#)

[< Previous](#)

2012 - Mazda6 - Brakes

BRAKES SST

49 0221 600C Disc brake expand tool		49 F043 002 Wrench		49 U043 004A Oil pressure gauge (Part of 49 U043 0A0A)	
49 U043 005 Joint (Part of 49 U043 0A0A)		49 U043 006 Hose (Part of 49 U043 0A0A)		—	

[< Previous](#)

[Back to Top](#)