

2012 - Mazda6 - Transmission/ Transaxle

NO.10 FREQUENT SHIFTING [FS5A-EL]

10	Frequent shifting
DESCRIPTION	Downshifting occurs suddenly even when accelerator pedal is depressed slightly in D position.
POSSIBLE CAUSE	The malfunctioning circuit is basically the same as No.9 "ABNORMAL SHIFTING". However, a malfunction of the input signal to the APP sensor, input/turbine speed sensor, vehicle speed sensor (including the sensor GND, sensor wiring harness and connector), or clutch slippage (clutch stuck, low pressure in line) may also be the cause.

2012 - Mazda6 - Transmission/ Transaxle

NO.10 FREQUENT SHIFTING [FS5A-EL]

10	Frequent shifting
DESCRIPTION	Downshifting occurs suddenly even when accelerator pedal is depressed slightly in D position.
POSSIBLE CAUSE	The malfunctioning circuit is basically the same as No.9 "ABNORMAL SHIFTING". However, a malfunction of the input signal to the APP sensor, input/turbine speed sensor, vehicle speed sensor (including the sensor GND, sensor wiring harness and connector), or clutch slippage (clutch stuck, low pressure in line) may also be the cause.