

2012 - Mazda6 - Transmission/ Transaxle

NO.11 SHIFT POINT IS HIGH OR LOW [FS5A-EL]

11	Shift point is high or low
DESCRIPTION	• Shift point considerably different from automatic shift diagram. • Shift delays when accelerating. • Shift occurs quickly when accelerating and engine speed does not increase.
POSSIBLE CAUSE	• If the transaxle does not shift abnormally, there is a malfunction of the input signal to the APP sensor, input/turbine speed sensor, or vehicle speed sensor (including sensor GND). • If the engine speed is high or low, regardless of normal shifting, inspect the tachometer. • Verify that the output signal of the APP sensor changes linearly. • Clutch or brake slippage NOTE: • If a tire of a different diameter from the standard tire is installed, the TCM determines that the driving mode is the AAS mode, and may change to a different shift timing from the normal timing.

2012 - Mazda6 - Transmission/ Transaxle

NO.11 SHIFT POINT IS HIGH OR LOW [FS5A-EL]

11	Shift point is high or low
DESCRIPTION	• Shift point considerably different from automatic shift diagram. • Shift delays when accelerating. • Shift occurs quickly when accelerating and engine speed does not increase.
POSSIBLE CAUSE	• If the transaxle does not shift abnormally, there is a malfunction of the input signal to the APP sensor, input/turbine speed sensor, or vehicle speed sensor (including sensor GND). • If the engine speed is high or low, regardless of normal shifting, inspect the tachometer. • Verify that the output signal of the APP sensor changes linearly. • Clutch or brake slippage NOTE: • If a tire of a different diameter from the standard tire is installed, the TCM determines that the driving mode is the AAS mode, and may change to a different shift timing from the normal timing.