

2012 - Mazda6 - HVAC

DTC U0423:68

DESCRIPTION	Invalid date received from instrument cluster
POSSIBLE CAUSE	- Instrument cluster malfunction - Climate control unit malfunction

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM INSTRUMENT CLUSTER DTC INSPECTION - Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER] .) - Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No Go to the next step.
2	PERFORM CLIMATE CONTROL UNIT DTC INSPECTION - Clear the DTC from the climate control unit memory using the M-MDS. (See CLEARING DTC.) - Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY.) - Is the same DTC present?	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No Go to the next step.
3	VERIFY TROUBLESHOOTING COMPLETED Clear the DTC from the climate control unit memory using the M-	Yes Replace the climate control unit, then go to the next step. (See CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION [FULL-AUTO AIR

	MDS. (See CLEARING DTC.) • Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY.) • Is the same DTC present?	CONDITIONER] .)	
		No	Go to the next step.
4	VERIFY THAT NO OTHER DTCs ARE RECORDED • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No	DTC troubleshooting completed.

2012 - Mazda6 - HVAC

DTC U0423:68

DESCRIPTION	Invalid date received from instrument cluster
POSSIBLE CAUSE	- Instrument cluster malfunction - Climate control unit malfunction

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM INSTRUMENT CLUSTER DTC INSPECTION - Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER] .) - Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No Go to the next step.
2	PERFORM CLIMATE CONTROL UNIT DTC INSPECTION - Clear the DTC from the climate control unit memory using the M-MDS. (See CLEARING DTC.) - Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY.) - Is the same DTC present?	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No Go to the next step.
3	VERIFY TROUBLESHOOTING COMPLETED Clear the DTC from the climate control unit memory using the M-	Yes Replace the climate control unit, then go to the next step. (See CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION [FULL-AUTO AIR

	MDS. (See CLEARING DTC.) • Perform the climate control unit DTC inspection using the M-MDS. (See DTC DISPLAY.) • Is the same DTC present?	CONDITIONER] .)	
		No	Go to the next step.
4	VERIFY THAT NO OTHER DTCs ARE RECORDED • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No	DTC troubleshooting completed.