




2012 - Mazda6 - HVAC




A/ C OPERATION CHECK MODE TABLE

M-MDS display	Target part	Operation condition
Illumination of All Indicator Lights	Climate control unit	All A/C indicator lights illuminated
Blower Motor Speed	Blower motor	OFF → 1ST → 3RD → 5TH → 7TH 
Air Mix Actuator	Air mix door	0 % → 50 % → 100 % → 50 % 
Air Flow Mode Actuator	Airflow mode door	VENT → BI-LEVEL → HEAT → HEAT/DEF → DEFROSTER 
Air Intake Actuator / Air Conditioning Compressor	Air intake door A/C compressor	FRESH REC ON OFF

*
Shown on the information display (at the set temperature display) according to each M-MDS display.

2012 - Mazda6 - HVAC

A/ C OPERATION CHECK MODE TABLE

M-MDS display	Target part	Operation condition
Illumination of All Indicator Lights	Climate control unit	All A/C indicator lights illuminated
Blower Motor Speed	Blower motor	OFF → 1ST → 3RD → 5TH → 7TH 
Air Mix Actuator	Air mix door	0 % → 50 % → 100 % → 50 % 
Air Flow Mode Actuator	Airflow mode door	VENT → BI-LEVEL → HEAT → HEAT/DEF → DEFROSTER 
Air Intake Actuator / Air Conditioning Compressor	Air intake door A/C compressor	FRESH REC ON OFF

*
Shown on the information display (at the set temperature display) according to each M-MDS display.