

[< Previous](#) [Next >](#)

2012 - Mazda6 - HVAC

AIR FILTER INSPECTION

1. Verify that there is no damage, excessive dirt, or abnormal odor on the air filter.
 - If there is any malfunction, replace the air filter.

NOTE:

- The air filter cannot be reused by cleaning it with water or compressed air.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - HVAC

AIR FILTER INSPECTION

1. Verify that there is no damage, excessive dirt, or abnormal odor on the air filter.
 - If there is any malfunction, replace the air filter.

NOTE:

- The air filter cannot be reused by cleaning it with water or compressed air.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.