

2012 - Mazda6 - Body and Accessories

SYMPTOM TROUBLESHOOTING [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)]

No.	TROUBLESHOOTING ITEM	PAGE
1	Fuel gauge needle position incorrect	(See NO. 1 FUEL GAUGE NEEDLE POSITION INCORRECT [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
2	All meters and gauges do not operate	(See NO. 2 ALL METERS AND GAUGES DO NOT OPERATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
3	ABS warning light illuminates	(See NO. 3 ABS WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
4	MIL illuminates	(See NO. 4 MIL ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
5	Brake system warning light illuminates	(See NO. 5 BRAKE SYSTEM WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
6	Instrument cluster illumination does not illuminate when taillights illuminate (standard meter)	(See NO. 6 INSTRUMENT CLUSTER ILLUMINATION DOES NOT ILLUMINATE WHEN TAILLIGHTS ILLUMINATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
7	Instrument cluster illumination does not dim when taillights illuminate (black out meter)	(See NO. 7 INSTRUMENT CLUSTER ILLUMINATION DOES NOT DIM WHEN TAILLIGHTS ILLUMINATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
8	Speedometer indication is defective	(See NO. 8 SPEEDOMETER INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
9	Tachometer indication is defective	(See NO. 9 TACHOMETER INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
10	Water temperature gauge indication is defective	(See NO. 10 WATER TEMPERATURE GAUGE INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
11	Malfunction warning light illuminates	(See NO. 11 MALFUNCTION WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)

2012 - Mazda6 - Body and Accessories

SYMPTOM TROUBLESHOOTING [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)]

No.	TROUBLESHOOTING ITEM	PAGE
1	Fuel gauge needle position incorrect	(See NO. 1 FUEL GAUGE NEEDLE POSITION INCORRECT [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
2	All meters and gauges do not operate	(See NO. 2 ALL METERS AND GAUGES DO NOT OPERATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
3	ABS warning light illuminates	(See NO. 3 ABS WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
4	MIL illuminates	(See NO. 4 MIL ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
5	Brake system warning light illuminates	(See NO. 5 BRAKE SYSTEM WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
6	Instrument cluster illumination does not illuminate when taillights illuminate (standard meter)	(See NO. 6 INSTRUMENT CLUSTER ILLUMINATION DOES NOT ILLUMINATE WHEN TAILLIGHTS ILLUMINATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
7	Instrument cluster illumination does not dim when taillights illuminate (black out meter)	(See NO. 7 INSTRUMENT CLUSTER ILLUMINATION DOES NOT DIM WHEN TAILLIGHTS ILLUMINATE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
8	Speedometer indication is defective	(See NO. 8 SPEEDOMETER INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
9	Tachometer indication is defective	(See NO. 9 TACHOMETER INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
10	Water temperature gauge indication is defective	(See NO. 10 WATER TEMPERATURE GAUGE INDICATION IS DEFECTIVE [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)
11	Malfunction warning light illuminates	(See NO. 11 MALFUNCTION WARNING LIGHT ILLUMINATES [INSTRUMENT CLUSTER (WITH MALFUNCTION WARNING LIGHT)] .)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.