


2012 - Mazda6 - Body and Accessories

FUEL-FILLER LID REMOVAL/ INSTALLATION

1. Remove the bolts.




2. Remove the fuel-filler lid.
3. Install in the reverse order of removal.
4. Adjust the fuel-filler lid. (See [FUEL-FILLER LID ADJUSTMENT](#))

2012 - Mazda6 - Body and Accessories

FUEL-FILLER LID REMOVAL/ INSTALLATION

1. Remove the bolts.



2. Remove the fuel-filler lid.
3. Install in the reverse order of removal.
4. Adjust the fuel-filler lid. (See [FUEL-FILLER LID ADJUSTMENT](#))