


2012 - Mazda6 - Body and Accessories

POWER OUTER MIRROR REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the inner garnish. (See [INNER GARNISH REMOVAL/ INSTALLATION.](#))
3. Remove the front door trim. (See [FRONT DOOR TRIM REMOVAL/ INSTALLATION.](#))
4. Disconnect the power outer mirror connector.




5. Remove the bolts.
6. Push the power outer mirror against the vehicle and detach the tab while lifting the mirror up to remove.
7. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

POWER OUTER MIRROR REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the inner garnish. (See [INNER GARNISH REMOVAL/ INSTALLATION.](#))
3. Remove the front door trim. (See [FRONT DOOR TRIM REMOVAL/ INSTALLATION.](#))
4. Disconnect the power outer mirror connector.



5. Remove the bolts.
6. Push the power outer mirror against the vehicle and detach the tab while lifting the mirror up to remove.
7. Install in the reverse order of removal.