

2012 - Mazda6 - Body and Accessories

POWER OUTER MIRROR SWITCH REMOVAL/ INSTALLATION

NOTE:

- The power outer mirror switch is integrated with the power window main switch.
1. Disconnect the negative battery cable.
 2. Remove the inner garnish. (driver-side) (See [INNER GARNISH REMOVAL/ INSTALLATION](#).)
 3. Remove the front door trim. (driver-side) (See [FRONT DOOR TRIM REMOVAL/ INSTALLATION](#).)
 4. Remove the power outer mirror switch. (See [FRONT DOOR TRIM DI SASSEMBLY/ ASSEMBLY](#).)
 5. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

POWER OUTER MIRROR SWITCH REMOVAL/ INSTALLATION

NOTE:

- The power outer mirror switch is integrated with the power window main switch.
1. Disconnect the negative battery cable.
 2. Remove the inner garnish. (driver-side) (See [INNER GARNISH REMOVAL/ INSTALLATION](#).)
 3. Remove the front door trim. (driver-side) (See [FRONT DOOR TRIM REMOVAL/ INSTALLATION](#).)
 4. Remove the power outer mirror switch. (See [FRONT DOOR TRIM DI SASSEMBLY/ ASSEMBLY](#).)
 5. Install in the reverse order of removal.