


[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

REARVIEW MIRROR REMOVAL

1. Remove the screw.



2. Pull out the rearview mirror in the direction of the arrow.

[< Previous](#) [Next >](#)

[Back to Top](#)


© 2012 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

REARVIEW MIRROR REMOVAL

1. Remove the screw.



2. Pull out the rearview mirror in the direction of the arrow.

[< Previous](#) [Next >](#)

[Back to Top](#)