

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

PERSONALIZATION FEATURES SETTING PROCEDURE

Exterior Open/ close Function Switching

- The switching of exterior open/close function is controlled by the BCM. (See [CONTROL SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE](#))

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

PERSONALIZATION FEATURES SETTING PROCEDURE

Exterior Open/ close Function Switching

- The switching of exterior open/close function is controlled by the BCM. (See [CONTROL SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE](#))

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.