


2012 - Mazda6 - Body and Accessories

RECLINER MOTOR INSPECTION

- 1. Disconnect the recliner motor connector.
- 2. Apply battery positive voltage to the recliner motor terminals and inspect the recliner motor operation.




- If not as specified, replace the front seat back frame. (See [FRONT SEAT BACK COMPONENT REMOVAL/ INSTALLATION](#).)

| Motor operation | Connection |     |
|-----------------|------------|-----|
|                 | B+         | GND |
| Forward         | E          | A   |
| Backward        | A          | E   |

2012 - Mazda6 - Body and Accessories

RECLINER MOTOR INSPECTION

- 1. Disconnect the recliner motor connector.
- 2. Apply battery positive voltage to the recliner motor terminals and inspect the recliner motor operation.



- If not as specified, replace the front seat back frame. (See [FRONT SEAT BACK COMPONENT REMOVAL/ INSTALLATION](#).)

| Motor operation | Connection |     |
|-----------------|------------|-----|
|                 | B+         | GND |
| Forward         | E          | A   |
| Backward        | A          | E   |