


2012 - Mazda6 - Body and Accessories

REAR SEAT BACK REMOVAL/ INSTALLATION

1. Remove the rear seat cushion. (See [REAR SEAT CUSHION REMOVAL/ INSTALLATION](#).)
2. Fold the rear seat back.
3. Remove the bolts.




4. Remove the rear seat back bracket from the rear seat back by pulling the rear seat back in the direction of the arrow shown in the figure.
5. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

REAR SEAT BACK REMOVAL/ INSTALLATION

1. Remove the rear seat cushion. (See [REAR SEAT CUSHION REMOVAL/ INSTALLATION](#).)
2. Fold the rear seat back.
3. Remove the bolts.



4. Remove the rear seat back bracket from the rear seat back by pulling the rear seat back in the direction of the arrow shown in the figure.

5. Install in the reverse order of removal.