


2012 - Mazda6 - Body and Accessories

POSITION MEMORY SWITCH REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the front seat side cover. (See [FRONT SEAT SIDE COVER REMOVAL/ INSTALLATION](#).)
3. Remove the screws, then remove the position memory switch.




4. Disconnect the position memory switch connector.
5. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

POSITION MEMORY SWITCH REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the front seat side cover. (See [FRONT SEAT SIDE COVER REMOVAL/ INSTALLATION](#).)
3. Remove the screws, then remove the position memory switch.



4. Disconnect the position memory switch connector.
5. Install in the reverse order of removal.