


2012 - Mazda6 - Body and Accessories

DOOR LOCK STRIKER REMOVAL/ INSTALLATION

1. Remove the screws, then remove the door lock striker.




2. Install in the reverse order of removal.
3. Adjust the door lock striker. (See [DOOR ADJUSTMENT](#).)

2012 - Mazda6 - Body and Accessories

DOOR LOCK STRIKER REMOVAL/ INSTALLATION

1. Remove the screws, then remove the door lock striker.



2. Install in the reverse order of removal.
3. Adjust the door lock striker. (See [DOOR ADJUSTMENT](#).)