


2012 - Mazda6 - Body and Accessories


FRONT DOOR LATCH AND LOCK ACTUATOR INSPECTION

1. The following actuators and switches are integrated with the front door latch and lock actuator. Inspect the front door latch and lock actuator according to each inspection procedure for the following items.
- Front door lock actuator (See [FRONT DOOR LOCK ACTUATOR INSPECTION .](#))
 - Door lock-link switch (Vehicles with theft-deterrent system) (See [DOOR LOCK-LINK SWITCH INSPECTION .](#))
 - Door latch switch (See [FRONT DOOR LATCH SWITCH INSPECTION .](#))
 - Front door key cylinder (See [FRONT DOOR KEY CYLINDER SWITCH INSPECTION .](#))

LH



RH




2012 - Mazda6 - Body and Accessories

FRONT DOOR LATCH AND LOCK ACTUATOR INSPECTION

1. The following actuators and switches are integrated with the front door latch and lock actuator. Inspect the front door latch and lock actuator according to each inspection procedure for the following items.
- Front door lock actuator (See [FRONT DOOR LOCK ACTUATOR INSPECTION .](#))
 - Door lock-link switch (Vehicles with theft-deterrent system) (See [DOOR LOCK-LINK SWITCH INSPECTION .](#))
 - Door latch switch (See [FRONT DOOR LATCH SWITCH INSPECTION .](#))
 - Front door key cylinder (See [FRONT DOOR KEY CYLINDER SWITCH INSPECTION .](#))

LH



RH

