


2012 - Mazda6 - Body and Accessories

KEYLESS RECEIVER REMOVAL/ INSTALLATION

- 1. Disconnect the negative battery cable.
- 2. Remove the glove compartment. (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
- 3. Remove in the order indicated in the table.




1	Connector
2	Nut
3	Keyless receiver

- 4. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

KEYLESS RECEIVER REMOVAL/ INSTALLATION

- 1. Disconnect the negative battery cable.
- 2. Remove the glove compartment. (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
- 3. Remove in the order indicated in the table.



1	Connector
2	Nut
3	Keyless receiver

- 4. Install in the reverse order of removal.

