




2012 - Mazda6 - Body and Accessories

TRUNK LID LATCH AND RELEASE ACTUATOR INSPECTION

1. The following actuator and switch are integrated with the release actuator. Inspect the trunk lid latch and release actuator according to each inspection procedure for the following items.

- Trunk lid latch switch (See [TRUNK LID LATCH SWITCH INSPECTION](#).)
- Trunk lid release actuator (See [TRUNK LID RELEASE ACTUATOR INSPECTION](#).)



2012 - Mazda6 - Body and Accessories

TRUNK LID LATCH AND RELEASE ACTUATOR INSPECTION

1. The following actuator and switch are integrated with the release actuator. Inspect the trunk lid latch and release actuator according to each inspection procedure for the following items.

- Trunk lid latch switch (See [TRUNK LID LATCH SWITCH INSPECTION](#).)
- Trunk lid release actuator (See [TRUNK LID RELEASE ACTUATOR INSPECTION](#).)

