


2012 - Mazda6 - Body and Accessories

TRUNK LID LOCK STRIKER REMOVAL/ INSTALLATION

1. Remove the trunk end trim. (See [TRUNK END TRIM REMOVAL/ INSTALLATION](#).)
2. Remove the bolts, then remove the trunk lid lock striker.




3. Install in the reverse order of removal.
4. Adjust the liftgate lock striker. (See [TRUNK LID ADJUSTMENT](#).)

2012 - Mazda6 - Body and Accessories

TRUNK LID LOCK STRIKER REMOVAL/ INSTALLATION

1. Remove the trunk end trim. (See [TRUNK END TRIM REMOVAL/ INSTALLATION](#).)
2. Remove the bolts, then remove the trunk lid lock striker.



3. Install in the reverse order of removal.
4. Adjust the liftgate lock striker. (See [TRUNK LID ADJUSTMENT](#).)