


## 2012 - Mazda6 - Body and Accessories

### THEFT-DETERRENT SYSTEM READING FREEZE FRAME DATA

1. Connect the M-MDS (IDS) to the DLC-2.



2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.

- When using the IDS (laptop PC)
  1. Select "Body".
  2. Select "Burglar Service Functions".

3. Then, select the following item from the screen menu.


- Select "Read FFD".

4. Read the record according to the directions on the screen.

## 2012 - Mazda6 - Body and Accessories

### THEFT-DETERRENT SYSTEM READING FREEZE FRAME DATA

1. Connect the M-MDS (IDS) to the DLC-2.



2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - When using the IDS (laptop PC)
    1. Select "Body".
    2. Select "Burglar Service Functions".
3. Then, select the following item from the screen menu.
  - Select "Read FFD".
4. Read the record according to the directions on the screen.