


2012 - Mazda6 - Body and Accessories

SPLASH SHIELD REMOVAL/ INSTALLATION

1. Remove the screw A, D, cap nut B and fastener C.
2. Pull the splash shield in the direction of the arrow shown in the figure then remove the tab E and F.




3. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

SPLASH SHIELD REMOVAL/ INSTALLATION

1. Remove the screw A, D, cap nut B and fastener C.
2. Pull the splash shield in the direction of the arrow shown in the figure then remove the tab E and F.



3. Install in the reverse order of removal.