



2012 - Mazda6 - Body and Accessories

FRONT MUDGUARD REMOVAL/ INSTALLATION

1. Remove screws A and tab B, and set the front mudguard out of the way in the direction of the arrow shown in the figure.



2. Remove fasteners C, E, F and screws D.



3. Remove the front mudguard in the direction of the arrow shown in the figure.

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)


2012 - Mazda6 - Body and Accessories

FRONT MUDGUARD REMOVAL/ INSTALLATION

1. Remove screws A and tab B, and set the front mudguard out of the way in the direction of the arrow shown in the figure.



2. Remove fasteners C, E, F and screws D.



3. Remove the front mudguard in the direction of the arrow shown in the figure.

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)