


2012 - Mazda6 - Body and Accessories

REAR MUDGUARD REMOVAL/ INSTALLATION

1. Remove the splash shield. (See [SPLASH SHIELD REMOVAL/ INSTALLATION](#))
2. Remove the cap nuts A, B and fastener C.




3. Remove the rear mudguard in the direction of the arrow shown in the figure.
4. Install in the reverse of removal.

2012 - Mazda6 - Body and Accessories

REAR MUDGUARD REMOVAL/ INSTALLATION

1. Remove the splash shield. (See [SPLASH SHIELD REMOVAL/ INSTALLATION](#))
2. Remove the cap nuts A, B and fastener C.



3. Remove the rear mudguard in the direction of the arrow shown in the figure.
4. Install in the reverse of removal.