


## 2012 - Mazda6 - Body and Accessories

### AERODYNAMIC UNDER COVER NO.2 REMOVAL/ INSTALLATION

1. Lift up the vehicle.
2. Remove the bolts.



3. Move the aerodynamic under cover No.2 in the direction of the arrow (1) shown in the figure.

**CAUTION:**

- Be careful not to damage the aerodynamic under cover No.2 during removal.

4. Remove the aerodynamic under cover No.2 in the direction of the arrow (2) shown in the figure.

5. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)

## 2012 - Mazda6 - Body and Accessories

### AERODYNAMIC UNDER COVER NO.2 REMOVAL/ INSTALLATION

1. Lift up the vehicle.
2. Remove the bolts.



3. Move the aerodynamic under cover No.2 in the direction of the arrow (1) shown in the figure.

**CAUTION:**

- Be careful not to damage the aerodynamic under cover No.2 during removal.

4. Remove the aerodynamic under cover No.2 in the direction of the arrow (2) shown in the figure.

5. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)