


2012 - Mazda6 - Body and Accessories

DECORATION PANEL REMOVAL/ INSTALLATION

Driver-side


1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION](#))
2. Pull the decoration panel in the direction of the arrow in the order of (1) and (2), then remove it while detaching the hooks A, clips B and pin C.



3. Remove the decoration panel.
4. Install in the reverse order of removal.

Passenger-side

1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION](#))
2. Pull the decoration panel in the direction of the arrow in the order of (1) and (2), then remove it while detaching the hooks A, clips B and pin C.



3. Remove the decoration panel.

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.


[Back to Top](#)

2012 - Mazda6 - Body and Accessories

DECORATION PANEL REMOVAL/ INSTALLATION

Driver-side


1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION](#))
2. Pull the decoration panel in the direction of the arrow in the order of (1) and (2), then remove it while detaching the hooks A, clips B and pin C.



3. Remove the decoration panel.
4. Install in the reverse order of removal.

Passenger-side

1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION](#))
2. Pull the decoration panel in the direction of the arrow in the order of (1) and (2), then remove it while detaching the hooks A, clips B and pin C.



3. Remove the decoration panel.

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)