



2012 - Mazda6 - Body and Accessories

COLUMN COVER REMOVAL/ INSTALLATION

1. Pull down the steering wheel.
2. Remove the blind rubber. (See [METER HOOD REMOVAL/ INSTALLATION](#).)
3. Pull the upper column cover in the direction of the arrow in the order of (1) and (2), then remove the upper column cover while detaching the tabs and pin.



4. Pull up the steering wheel.
5. Remove the screws.
6. Remove the lower column cover in the direction of the arrow (4) while keeping it open in the direction of the arrow (3) shown in the figure.



7. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)


2012 - Mazda6 - Body and Accessories

COLUMN COVER REMOVAL/ INSTALLATION

1. Pull down the steering wheel.
2. Remove the blind rubber. (See [METER HOOD REMOVAL/ INSTALLATION](#).)
3. Pull the upper column cover in the direction of the arrow in the order of (1) and (2), then remove the upper column cover while detaching the tabs and pin.



4. Pull up the steering wheel.
5. Remove the screws.
6. Remove the lower column cover in the direction of the arrow (4) while keeping it open in the direction of the arrow (3) shown in the figure.



7. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)