


2012 - Mazda6 - Body and Accessories

TRUNK END TRIM REMOVAL/ INSTALLATION

1. Open the trunk lid.
2. Remove the trunk mat.
3. Remove the trunk board.
4. Remove the fasteners A.




5. Pull the trunk end trim in the direction of the arrow shown in the figure and remove it while detaching the pins B, D and clips C.
6. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

TRUNK END TRIM REMOVAL/ INSTALLATION

1. Open the trunk lid.
2. Remove the trunk mat.
3. Remove the trunk board.
4. Remove the fasteners A.



5. Pull the trunk end trim in the direction of the arrow shown in the figure and remove it while detaching the pins B, D and clips C.
6. Install in the reverse order of removal.