


2012 - Mazda6 - Body and Accessories

FRONT DOOR TRIM DISASSEMBLY/ ASSEMBLY

Driver-side


- 1. Disassemble in the order shown in the figure.
- 2. Assemble in the reverse order of disassembly.



1	Insulator
2	Weatherstrip
3	Main switch panel
4	Screw
5	Power window main switch

Passenger-side

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassemble.



1 Insulator

2 Weatherstrip

3 Subswitch panel

4 Screw

5 Power window subswitch


6 Front door trim

2012 - Mazda6 - Body and Accessories

FRONT DOOR TRIM DISASSEMBLY/ ASSEMBLY

Driver-side


- 1. Disassemble in the order shown in the figure.
- 2. Assemble in the reverse order of disassembly.



1	Insulator
2	Weatherstrip
3	Main switch panel
4	Screw
5	Power window main switch

Passenger-side

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassemble.



1 Insulator

2 Weatherstrip

3 Subswitch panel

4 Screw

5 Power window subswitch

6 Front door trim

