


2012 - Mazda6 - Body and Accessories

GLOVE COMPARTMENT LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the glove compartment. (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.




1	Socket
2	Glove compartment light bulb

4. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

GLOVE COMPARTMENT LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the glove compartment. (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.



1	Socket
2	Glove compartment light bulb

4. Install in the reverse order of removal.