


## 2012 - Mazda6 - Body and Accessories

### AUTO LIGHT-OFF CONTROL MODULE REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the dashboard under cover (Driver side). (See [DASHBOARD UNDER COVER REMOVAL/ INSTALLATION.](#))
3. Remove the nut.




4. Disconnect the connectors.
5. Remove the auto light-off control module.
6. Install in the reverse order of removal.

## 2012 - Mazda6 - Body and Accessories

### AUTO LIGHT-OFF CONTROL MODULE REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the dashboard under cover (Driver side). (See [DASHBOARD UNDER COVER REMOVAL/ INSTALLATION.](#))
3. Remove the nut.



4. Disconnect the connectors.
5. Remove the auto light-off control module.
6. Install in the reverse order of removal.