


2012 - Mazda6 - Body and Accessories

PARKING/ FRONT TURN LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Slightly bend back the mudguard. (See [FRONT MUDGUARD REMOVAL/ INSTALLATION.](#))
3. Rotate the parking/front turn light socket in the direction of the arrow (1) shown in the figure.




4. Pull the parking/front turn light socket in the direction of the arrow (2) shown in the figure and remove it.
5. Remove the parking/front turn light bulb.
6. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

PARKING/ FRONT TURN LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Slightly bend back the mudguard. (See [FRONT MUDGUARD REMOVAL/ INSTALLATION.](#))
3. Rotate the parking/front turn light socket in the direction of the arrow (1) shown in the figure.



4. Pull the parking/front turn light socket in the direction of the arrow (2) shown in the figure and remove it.
5. Remove the parking/front turn light bulb.
6. Install in the reverse order of removal.