



2012 - Mazda6 - Body and Accessories

SIDE TURN LIGHT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the outer mirror glass. (See [OUTER MIRROR GLASS REMOVAL.](#)) (See [OUTER MIRROR GLASS INSTALLATION.](#))
3. Remove the outer mirror garnish. (See [OUTER MIRROR GARNISH REMOVAL/ INSTALLATION.](#))
4. Remove the screw.



5. Disconnect the connector.



6. Remove the side turn light.

7. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.


2012 - Mazda6 - Body and Accessories

SIDE TURN LIGHT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the outer mirror glass. (See [OUTER MIRROR GLASS REMOVAL.](#)) (See [OUTER MIRROR GLASS INSTALLATION.](#))
3. Remove the outer mirror garnish. (See [OUTER MIRROR GARNISH REMOVAL/ INSTALLATION.](#))
4. Remove the screw.



5. Disconnect the connector.



6. Remove the side turn light.

7. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.