



2012 - Mazda6 - Body and Accessories

REAR TURN LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the trunk end trim. (See [TRUNK END TRIM REMOVAL/ INSTALLATION](#).)
3. Partially peel back the trunk side trim. (See [TRUNK SIDE TRIM REMOVAL/ INSTALLATION](#).)
4. Disconnect the connectors shown in the figure.



5. Rotate the rear turn light socket in the direction of the arrow shown in the figure and remove it.




6. Remove the rear turn light bulb.
7. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

REAR TURN LIGHT BULB REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the trunk end trim. (See [TRUNK END TRIM REMOVAL/ INSTALLATION](#).)
3. Partially peel back the trunk side trim. (See [TRUNK SIDE TRIM REMOVAL/ INSTALLATION](#).)
4. Disconnect the connectors shown in the figure.



5. Rotate the rear turn light socket in the direction of the arrow shown in the figure and remove it.



6. Remove the rear turn light bulb.
7. Install in the reverse order of removal.

